

Greenhouse Irrigation System User Manual

Step 1: Preparation

- Open the package and inspect all parts for any damage.
- Ensure the area in your greenhouse where you intend to install the irrigation system is clear.

Step 2: Install Main Pipeline

- Lay out the main pipeline along the edge of the greenhouse or the area you want to irrigate.
- Use the provided connectors to join the main pipeline sections, ensuring tight seals to prevent leaks.

Step 3: Install Sprinklers

- Choose suitable locations along the main pipeline to install the sprinklers.
- Use the provided attachments to connect the sprinklers to the main pipeline, ensuring tight connections and proper alignment of the sprinklers.

Step 4: Adjust Sprinklers

- Adjust the angle and range of the sprinklers according to your needs and the positioning of your plants.
- Ensure each plant receives sufficient water coverage.

Step 5: Connect Water Source

- Attach a hose to the inlet of the main pipeline and connect the other end to your water source.
- Turn on the water source and check that the sprinklers are functioning properly without any leaks or blockages.

Step 6: Adjust Water Flow

- Adjust the water pressure from the water source as needed to ensure the sprinklers provide the appropriate flow of water without wastage.

Step 7: Routine Maintenance

- Regularly inspect the sprinklers and pipeline connections for any leaks or damage.
- Clean the sprinklers and pipeline to ensure they function properly.

Notes:

- Exercise caution when installing and adjusting the sprinklers to avoid directing water towards electronic equipment or other vulnerable items in the greenhouse.
- In case of any issues, immediately shut off the water source and check the sprinklers and pipeline connections for proper installation.

We hope this user manual helps you correctly install and utilize the MIXC Greenhouse Irrigation System, ensuring your plants receive adequate water for healthy growth.