



Thank you for purchasing the BLACK SHARK Lucifer T14 Wireless Earbuds. Please read this manual carefully and keep it for future reference. If you need any assistance, please contact our support team with your product model number and Amazon order number.

■ PACKAGE CONTENTS

BLACK SHARK Lucifer T14



CHARGING CASE



CHARGING CABLE



USER MANUAL & WARRANTY CARD

■ SPECIFICATIONS



Model	BS-T14
Bluetooth Version	Bluetooth 5.0
Transmission Distance	≤ 10 m
Driver Size	13 mm x 2
Frequency Response	20 Hz -20 kHz
Battery Capacity	35 mAh x 2 (earbuds), 300 mAh (charging case)
Charging Time	1.5 h
Play Time (varies by volume level and content)	4 h (A total of 16 h with the charging case)
Charging Type	USB-C
Casing Material	ABS, PC
Cable Material	PVC
Cable Length	0.3m
Compatibility	Devices with Bluetooth audio capability
Supported Codecs	SBC, AAC

■ GETTING STARTED



CHARGING YOUR BLACK SHARK LUCIFER T14

For first-time use, connect the charging case (containing the earbuds) to a USB port via the charging cable and wait until your Lucifer T14 is fully charged. For subsequent use, the charging case and earbuds can be charged independently.



BATTERY INDICATOR FOR THE CHARGING CASE WHEN PLUGGED IN



Indicator	Status
Flash 	Charging
Static 	Fully charged

BATTERY INDICATOR FOR THE CHARGING CASE WHEN UNPLUGGED

Indicator	Status
Flash 	Battery <10%
Static 	Battery >10%

● Open the case to check the power. When the power is less than 10%, the indicator flashes in white (statics white when more than 10%); It goes out after 8 seconds. If close the case the indicator goes out immediately.

Indicator	Status
Flash 	Earbuds in
Flash 	Earbuds out

Indicator	Status
Flash x1 	1 earbuds charging
Flash x2 	2 earbuds charging

● No indicator prompt if earbuds are not on charge.

PAIRING TO A MOBILE DEVICE

● When connecting your Lucifer T14, remember to keep it within a meter (1m) of your mobile device.

- Simply open the case to enter pairing mode.
- You will hear "Power on" while the earbuds are powered on and enter pairing mode.
 - You will hear 2 dong sounds while the earbuds auto-pairing was successful.

- ❶ *The first earbud to boot is the master earbud.*
- 2. Enable Bluetooth on your mobile device and select "Black Shark Lucifer T14" from the list of the device found.
- 3. Wait for pairing to complete.
- You will hear "Connected" when the earbuds have successfully paired and connected to your device.
- If the earbuds fail to connect to your audio source, the earbuds will stay in search mode for up to 5 minutes before powering off. If this happens, simply repeat the steps again to pair.
- ❶ *Once the earbuds have been paired, they will automatically try to connect to the paired mobile device each time the charging case is opened or the earbuds are powered on.*

POWER ON/OFF

To power off the device, simply return the earbuds to the charging case and close the case. The earbuds will power back up when you open the case or hold both touch controls for 3 seconds.

USING THE LEFT/RIGHT EARBUD ONLY

Simply take the left/right earbud out only and connect it to your device. There is no prompt when using one side earbud only.

■ TOUCH CONTROLS FOR EARBUDS

FUNCTION	ACTION	AUDIO PROMPT
Power On	Open the case	"Power On"
	Hold both touch controls for 3 seconds	
Power Off	Place the earbuds back in the case and close it	None
Automatic shut-down	Fail connected to the device for 5 minutes / low power	"Power Off"
Pairing	Open the case	2 dong sounds
Connected	Open the case	"Connected"
Standby	None	None
Disconnect	Disconnect via the connected device	"Disconnected"

Voice Assistant	Hold the L/R touch control for 3 seconds	1 beep sound
Answer a call	Double tap the L/R touch control	Ringtone: 4 beep sounds
End a call	Double tap the L/R touch control	1 beep sound
Reject a Call	Hold the L/R touch control for 2 seconds	None
Play/Pause	Double tap the L/R touch control	None
Previous Track	Triple tap the left touch control	None
Next Track	Triple tap the right touch control	None
Battery Low	None	"Please Charge"
Force pairing	Quintuple tap both touch control and wait 15 seconds	2 dong sounds

■ SAFETY INFORMATION

Avoid Hearing Damage



Using the earbuds at a high volume for a long time may cause permanent hearing loss. To reduce this risk, keep the volume at a safe and comfortable level.

Traffic Security

To reduce the risk of accidents, always fully pay attention while driving. Using a device while driving, even with a hands free kit, distracts you and can cause an accident. Follow local driving laws and regulations while using this device.

Interference with Medical Equipment

This device may cause medical equipment to malfunction. Therefore, follow all rules and regulation of hospitals and health care facilities. Do not use your device in prohibited areas. Some wireless devices may affect the performance of hearing aids and pacemakers. Consult your service provider for more information. Pacemaker manufacturers advise keeping a minimum distance of 15 cm between a mobile device and pacemaker to prevent potential interference. It is recommended to hold the device opposite the pacemaker, and not to carry the device in your front pocket.

Battery

This product contains a lithium-ion battery. WARNING! There is a risk of explosion if the battery is replaced by an incorrect type. Do not attempt to remove, open,

crush, puncture, short circuit, dispose of in fire or water, or expose battery to temperatures higher than 40°C. Dispose of used batteries according to local regulations.

Battery Replacement

Your device's battery is built-in and non-removable. The battery can be replaced only by an authorized service partner, whose contact information can be found on the Warranty card.

The operating temperature of the device is -15 to 55°C. Avoid environments that are dusty, damp, dirty, or have magnetic fields. Keep the device away from extended-period direct sunlight, extreme heat/cold, fire, microwave, or high-pressure containers. Such environments may damage your device or accessories.



Correctly dispose of this product. This icon indicates that this product should not be disposed with other household wastes throughout the EU. To prevent the environment or human health from being damaged due to uncontrolled waste disposal, recycle responsibly to promote the sustainable reuse of material resources. To safely recycle your device, use return and collection systems or contact the retailer from whom you purchase the device.

■ WARRANTY & CUSTOMER SUPPORT

For questions, support, or warranty claims, please contact us through one of the region-specific email addresses given below. Please include your Amazon order number and product model number.

[Amazon US orders: support.us@blackshark.com](mailto:support.us@blackshark.com)

[Amazon EU orders: support.eu@blackshark.com](mailto:support.eu@blackshark.com)

[Amazon CA orders: support.ca@blackshark.com](mailto:support.ca@blackshark.com)

[Amazon JP orders: support.jp@blackshark.com](mailto:support.jp@blackshark.com)

For more information, please check on global.blackshark.com

Join Black Shark at global.blackshark.com

Like us on Facebook at facebook.com/BlackSharkGlobal

Follow us on Twitter at twitter.com/blckshrkr_global

Manufacturer: Blackshark Technologies (Nanchang) Co., Ltd.

Registered Address: Room 815-1, 8th floor, Block A, Huajiang Building, NO.1 Tsinghua Science Park, NO.299, Yupingdong Street, Nanchang Economic and Technological Development Zone, Nanchang City, Jiangxi Province, 330013, CN

FCC ID: 2A2JO-BST1

IC: 27499-BST14



210-163772



RoHS
Made in China