

User guide for earbuds and Charging

4 Check the Charging Indicator

- Look for the LED indicator on the charging case to ensure it's charging. It should light up or blink to signify that charging has begun.
- Some charging pads may also have an indicator light to show that the device is charging.

5 Charging Time

- Allow the earbuds to charge fully. The time required may vary depending on the battery level and the charging pad used.
- Check the manufacturer's guidelines for specific charging times.

6 Remove from Charging Pad

- Once fully charged, remove the charging case from the pad.
- Your earbuds are now ready for use, providing you with hours of uninterrupted audio.

7 Safety Tips

- Do not place any metal objects between the charging pad and the charging case.
- Avoid using the wireless charger in extreme temperatures or humid environments.
- If you experience any issues, refer to the troubleshooting section of your user manual or contact customer support.



1 Battery Life Indicator 2 Type-C Charging Port 3 Ear Tip
4 Status Button 5 Bluetooth Indicator Light 6 Microphone
7 Magnetic Charge Pins 8 Touch Control 9 Status Light

SPECIFICATIONS

Model: GROOVZ (XY-16)
Bluetooth: v5.3
Bluetooth Range: 32 feet
Earbud Battery: 30mAh
Charging Case Battery: 400mAh



BOX CONTENTS

Bluetooth Headsets
Headphone Charging Case
Type-C Charging Cable
User Guide
Set of Interchangeable Earbud Tips

Thank you for your purchase and we hope you enjoy your new Groovz Headphones.

We are here to help :)

Please reach out with any questions or concerns:
support@groovzaudio.com

GROOVZ

Visit us at
www.groovzaudio.com
for exciting product offers and to register your warranty.

@Groovzaudio
 @groovzaudio

GROOVZ

USER GUIDE

3.06"
3.06"
3.06"
3.1"
3.1"

outside

CARE INSTRUCTION

Please read carefully before use

Headphones should be stored in a cool, dry environment. Avoid contact with oil, water vapor and steam to avoid affecting performance and voiding warranty. Avoid cleaning with irritant solutions. Headset should be used in accordance to the correct specification requirements. Do not remove plastic exterior casing of earbuds without permission. Only use approved type-c charging cable to charge device.

WARRANTY INFORMATION

Groovz headphones come with a 1-Year Limited Warranty from the date of purchase. The warranty covers defects in materials and workmanship. The warranty does not cover damage to the product as a result of misuse or accidents. Should your product become defective during the 1-Year warranty period, we will repair or replace (at our option) your product. Please reach out to customer support via support@groovzaudio.com to register for your warranty and to report any defect in your product. Groovz and its parent company shall not be held liable for an incidental or consequential damages arising from any defects in this product.

INSTRUCTION

Power ON

Powering ON option#1 (auto mode)

- Open top cover of charging case
- Remove earbud from case. Earbud will enter pairing mode automatically.

Powering ON option#2 (manually)

- With earbuds already removed from charging case, ensure earbuds are powered off.
- Press & Hold both left and right earbud touch control locations for 5 seconds.

Bluetooth Pairing

Connected to your device

- Remove earbuds from charging case.
- Turn ON Bluetooth from Parent device.
- Find bluetooth device "Groovz" in list of pairing options on Parent device.
- Click to connect, and Groovz earbuds will announce successful connection.

*Previously paired devices will connect within 2-4 seconds of power-on.

TOUCH (TAP) CONTROL FUNCTIONS

Phone Call Functions

Answer/ Hang Up/ Dismiss

- tap either earbuds on touch control function to answer/ end phone call.
- press & hold either earbuds for 1.5 seconds to dismiss phone call.

Audio Listening Functions

Play Track

- tap either earbuds 1x to pause or play audio track.

Skip/ Previous Track

- tap left earbuds 2x to replay previous track;
- tap right earbuds 2x to skip to next track.

Volume Controls

- tap left earbuds 3x to increase volume;
- tap right earbuds 3x to decrease volume.

Smart Assistant Controls

- press & hold right earbuds 1.5 seconds to activate smart assistant.

How to Use Qi Wireless Charging with Your True Wireless Earbuds

- Ensure Compatibility**
 - Confirm that your True Wireless Earbuds and charging case are compatible with Qi wireless charging.
 - Use a Qi-certified wireless charging pad for optimal performance.
- Prepare the Charging Pad**
 - Plug in your Qi wireless charging pad to a power source using the provided cable and adapter.
 - Place the charging pad on a flat, stable surface.
- Position the Charging Case**
 - Place your earbuds inside the charging case and close the lid securely.
 - Position the charging case on the center of the wireless charging pad. Ensure the case is aligned correctly with the charging pad.

3.1"
3.1"
3.06"
3.06"
3.06"

inside



Bleed: 0,04" all around
The image is not the color proof

C 35	C 0
Y 10	Y 0
M 10	M 0
K 0	K 20