

K10 Pro Bluetooth Mechanical Keyboard



Search "RGB keymap" here to download the JSON file if VIA does not automatically recognize keymap of the K10 Pro:

https://www.keychron.com/blogs/archived/k10-pro-factory-reset-and-firmware-flash

VIA Software for macOS, Windows, Linux: <a href="https://usevia.app/#/">https://usevia.app/#/</a>

How to Use VIA on Your Keychron K Pro Series Keyboard:

https://www.keychron.com/blogs/archived/how-to-use-via-to-program-your-keyboard

K10 Pro Source Code, please search "source code" on the product page on our official website.

## IN THE BOX:

Keychron K10 Pro Bluetooth Mechanical Keyboard x 1

Type-C Cable x 1

Manual x 1


Quick Start Guide x 1

Extra Keycaps Set x 1


### **QUICK START GUIDE**

If you are a Windows user, please find the appropriate keycaps in the box, then follow the instructions below to find and replace the following keycaps.

Mac / Windows



#### 1 Connect Bluetooth



### 2 Connect Cable



### 3 The VIA Key Remapping Software

Please visit <u>caniusevia.com</u> to download the latest VIA software to remap the keys. If the VIA software cannot recognize your keyboard, please reach out to our support to get the instruction. (VIA only works when the keyboard is connected by wire to the computer.)



### 4 The Lavers

There are four layers of key settings on the keyboard. The layer 0 and layer 1 are for the Mac system. The layer 2 and layer 3 are for the Windows system.



If your system toggle is switched to Mac, then the layer 0 will be activated




If your system toggle is switched to Windows, then the layer 2 will be activated. Remember that if you are using it in Windows mode, please make changes to the layer 2 instead of the top layer (the layer 0). This is a common mistake people are making.




### **5** The Backlight

Press fn + Q to change the lighting effect




Press fn + tab to turn the backlight on/off




### 6 Adjust The Backlight Brightness

Press fn + W to increase the backlight brightness



Press fn + S to decrease the backlight brightness



#### 7 Activate Siri / Cortana

For Siri on Mac: Go to System preferences > Siri > select "Hold Command Space" option.

\*Siri key only works on macOS and does not work on iOS.



For Cortana on Windows: Select Start > Settings > Cortana and select the shortcut by pressing Windows key + C key.

\*Windows Cortana is only available for Windows 10 and above OS. Cortana is only available in certain countries / regions and might not work everywhere.



### **8** Warranty

The keyboard is highly customizable and easy to be rebuilt. If anything goes wrong with any of the keyboard components of keyboard during the warranty period, we will only replace the defective parts of the keyboard, not the whole keyboard.




### **9** Watch The Building Tutorial On Our Website

If you are building the keyboard for the first time, we highly recommend you watch the building tutorial video on our website first, then start building the keyboard yourself.



### 10 Factory Reset



Troubleshooting? Don't know what's going on with the keyboard?

- 1) Plug in the power cable and switch the keyboard to Cable mode.
- ② Factory reset the keyboard by pressing fn + J + Z (for 4 seconds).
- (3) Download the right firmware and QMK Toolbox from our website.
  (4) Switch the keyboard to OFF mode and remove the space bar keycap
- to find the reset button on the PCB.
- S Hold the reset key first, then switch the keyboard to Cable mode. Release the reset key, and the keyboard will now enter DFU mode.
- (6) Flash the firmware with the QMK Toolbox.
- 7) Factory reset the keyboard again by pressing fn + J + Z (for 4 seconds).
- \* Step by step guide can be found on our website.

#### K10 PRO BLUETOOTH MECHANICAL KEYBOARD SPECIFICATIONS

Number of keys: 108 Switch type: Mechanical Battery: 4000mAh

Bluetooth working time (RGB): Up to 100 hours (Lowest brightness)

Charging time: Around 3 hours Charging port: USB Type-C Mode: Bluetooth / Wired


Bluetooth operating distance: Within 10 meters (open space)

Name of Bluetooth device: Keychron K10 Pro

Operating Environment: -10 to 50°c

Technical specifications can be subjected to change without notice we apologize for any inconvenience caused.

### K10 PRO BLUETOOTH MECHANICAL KEYBOARD OVERVIEW










- 1 Charging indicator
- ② Bluetooth indicator
- ③ Caps Lock indicator
- 4 Charging port
- (5) Win/Android Mac/iOS (OS Toggle Switch)
- 6 BT OFF Cable (Mode Toggle Switch)

#### **DEFAULT KEY LAYOUT:**

LAYER 0: This layer will be activated when your keyboard's system toggle is switched to Mac.



LAYER 1: This layer will be activated when your keyboard's system toggle is switched to Mac and press the fn/MO(1) key.



LAYER 2: This layer will be activated when your keyboard's system toggle is switched to Windows.



LWin = Left Windows LAIt = Left Alt RAIt = Right Alt RWin = Right Windows RCtl = Right Ctrl

LAYER 3: This layer will be activated when your keyboard's system toggle is switched to Windows and press the fn/MO(3) key.



### **KEY DESCRIPTION**

| Key Description |                            | Key Description |   |
|-----------------|----------------------------|-----------------|---|
| Scr-            | Screen Brightness Decrease | RGBMd-          | RGB Mode Previous                               |
| Scr+            | Screen Brightness Increase | Hue+            | Hue Increase                                    |
| Bright-         | Backlight Decrease         | Hue-            | Hue Decrease                                    |
| Bright+         | Backlight Increase         | RGB SPI         | RGB Speed Increase                              |
| Prvs            | Previous                   | RGB SPD         | RGB Speed Decrease                              |
| Play            | Play/Pause                 | MO(1)           | Layer 1 will be activated when holding this key |
| Next            | Next                       | MO(2)           | Layer 2 will be activated when holding this key |
| Mute            | Mute                       | MO(3)           | Layer 3 will be activated when holding this key |
| Vol-            | Volume Decrease            | MO(4)           | Layer 4 will be activated when holding this key |
| Vol+            | Volume Increase            | BTH1            | Bluetooth Host 1                                |
| RGB Toggle      | Turn Backlight on/off      | BTH2            | Bluetooth Host 2                                |
| RGBMd+          | RGB Mode Next              | втнз            | Bluetooth Host 3                                |

#### LED STATUS OVERVIEW

| LED Location        | Function  | Status  |
|---------------------|-----------|---|
| Battery indicator   | Charging  | Low battery - Blinking Red<br>Charging - Static Red<br>Fully charged - Static Green |
| Bluetooth indicator | Bluetooth | Pairing - Slow Blinking<br>Paired - Light Off<br>Switching - Fast Blinking          |

# FUNCTION DESCRIPTION: CHARGING

Plug the cable into a USB port and plug the other end into the keyboard port. Charging Indicator: When battery is below 15%, a red battery blinking indicator will be triggered. A red light will stay on while charging; Fully charged in around 3 hours, a green battery indicator will appear.

\*The Keychron keyboard is compatible with all USB ports. Please use a 5V 2A adapter or USB 3.0 for the best performance. The Keychron K10 Pro can be charged in Bluetooth/on/off mode.

\*\*This product supports up to 5V charging voltage and 2A charging current. We are not responsible for any problems caused by improper charging.

### BLUETOOTH / WIRED MODE (MODE TOGGLE SWITCH)

#### WIRED MODE

- 1. Switch the toggle switch to the Cable option (it only works when a USB cable is plugged in).
- 2. Connect our cable with your PC and keyboard.
- 3. Backlighting will be turned on.
- \*Under Wired Mode, keyboard will not enter into Battery Saver Mode.

#### **BLUETOOTH MODE**

- 1. Switch the toggle switch to the Bluetooth option.
- 2. Backlighting will be turned on.
- 3. Hold "fn+1" key for 4 seconds to activate Bluetooth pairing (the Bluetooth indicator fast flashes for 3 minutes to detect pairing).
- 4. Search for the Bluetooth device "Keychron K10 Pro" on your device and connect it (the Bluetooth indicator goes off after successful pairing).

Note: This keyboard supports pairing up to 3 devices simultaneously via key combination "fn" + "1" / "fn" + "2" / "fn" + "3".

\*The Bluetooth indicator will continue to flash for 3 minutes.

\*\*Slow or failed connections may exist due to different Bluetooth versions, please make sure all the settings are correct.

#### SWITCH BLUETOOTH DEVICES

Short press key combination "fn" + "1" / "fn" + "2" / "fn" + "3" to switch to other device.

#### RECONNECT:

- 1. Switch the keyboard to the Bluetooth option to activate the keyboard.
- 2. The Bluetooth indicator flashes for 4 seconds and automatically pairs with the last paired device.
- 3. If the Bluetooth indicator is off, press any button to enter the connection again.
- \* The keyboard must have been paired with the device to perform this function.

#### TURN OFF THE KEYBOARD

Switch the keyboard to the OFF option.

#### **BACKLIGHT SETTING**

- Short press to switch between different types of lighting effects.
- When backlighting is on, press button to switch among them.

#### OS TOGGLE SWITCH

#### 1 - MAC/iOS

Switch the toggle to Mac/iOS when the keyboard is connected to a Mac or iOS operating system.

#### 2 - WINDOWS/ANDROID

Switch the toggle to Windows/Android when the keyboard is connected to a Windows or Android operating system.

\*When using the Windows/Android mode, 🔳 🕟 keys are used for "Windows" and "Alt" functions.

#### 3 – INPUT METHOD SWITCH

For iOS:

Input method switch: Ctrl + Space

Caps Lock: Caps (Enable General>Keyboards>Hardware Keyboard>Caps Lock Language Switch)

For Android:

Input method switch: Shift + Space

NOTE: Functions of certain multimedia key may be disabled due to compatibility, versions, brands and drivers of Windows/Android OS. We also recommend not to switch OS frequently as it may impact keyboard operations.

#### TROUBLESHOOTING

If unable to pair keyboard to device, confirm that the device you're trying to pair with is Bluetooth-capable. If so, restart the device and try pairing it with the keyboard again.

Note: On a Windows computer, a new Bluetooth connection will sometimes require additional software updates—a process that may still be ongoing after a message appears indicating a successful completion. Wait at least 20 minutes after pairing to make sure all updates are completed before restarting the computer.

Confirm that the device is configured to accept Bluetooth connections (Windows) and supports an external keyboard (HID profile).

Go to Bluetooth Devices > Open Settings and select the following: Allow Bluetooth devices to find this computer Allow Bluetooth devices to connect to this computer Alert me when a Bluetooth device wants to connect

### My keyboard isn't working.

For the computer/smartphone:

Go to your device Bluetooth settings>Select the keyboard and remove/delete/unpair it.

Then restart your device.

For the keyboard:

Turn the keyboard off and back on. Then reconnect it to your device.

#### Bluetooth connection is interrupted even within 10 meters.

Check if the keyboard is resting on a metal surface that can interfere with the Bluetooth signal.

#### Third-party input tools are not compatible with the keyboard.

Due to compatibility, versions, brands and drivers of Windows/Android OS, functions of third-party input tools may be affected while using the keyboard. Please make sure your operating system and drivers are up to date.

### Certain multimedia keys or function keys do not work.

Functions of certain multimedia keys may be disabled due to compatibility, versions, brands, and drivers of devices.

Function keys: F1 / F2 / F3 / F4 / F5 / F6 / F7 / F8 / F9 / F10 / F11 / F12

#### **Safety Precaution:**

Keep the product, accessories and packaging parts out of the reach of children to prevent any accidents and choking hazards.

Always keep the product dry to avoid corrosion.

Do not expose the product to extreme temperatures below -10°C(5°F) or above 50°C(131°F) to preserve the lifespan of the keyboard.

#### Keychron, Inc. Dover, DE 19901, United States

Find us at: https://www.keychron.com Support@keychron.com

🕜 @keychron

@keychron



Designed by Keychron

Made in China