



Original	Replacement
 Power	 Power
 Source	 AV
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 TTX/ M X	 Text
 PRE- CH	 Pre Ch
 Vol +	 Vol +
 Vol -	 Vol -
 Mute	 Mute

Original	Replacement
 CH Li st	 Li st
 CH+	 Ch +
 CH-	 Ch -
 Set t i n g s	 Opt i o n s
 Home	 Smart
 Gui de	 Gui de
 E- Manual	 D. Menu
 I n f o	 I n f o
 Ret ur n	 Back
 Exi t	 Exi t
 Up	 Up
 Down	 Down
 Ri ght	 Ri ght
 Lef t	 Lef t
 Ent er	 Ok
 Red	 Red
 Green	 Green





Original	Replacement
 Yellow	 Yellow
 Blue	 Blue
 Picture Size	 3D
 AD/Subt.	 Subt
 Picture	 Format
 << <<	 <<
 Stop	 Stop
 Play	 Play
 Pause	 Pause
 >> >>	 >>

Original	Replacement

