



ENGLISH



ATOM MK886 V2

MECHANICAL KEYBOARD

What's included in the box

1. FANTECH ATOM MK886v2 Mechanical Keyboard
2. User's manual

System requirements

1. Operating systems: Windows XP/7/8/10, MAC OS
2. One USB 2.0/3.0 port

USER MANUAL

Instruction Manual

Thankyou for purchasing Fantech ATOM MK886v2 Mechanical Keyboard. The ATOM MK886v2 features mechanical switches and wired USB connectivity for all of your gaming adventures!

Fantech ATOM MK886v2 is plug and play, no need to install any driver for your first use.



Technical Specification

- Product name : FANTECH ATOM MK886v2 Mechanical Keyboard
- Number of keys : 104 keys
- Switch type : Mechanical
- Anti-Ghosting : 25 Keys Anti-ghosting
- Size : 435(L)x127(W)x32(H)mm
- Weight : 700g


Size



Multimedia




How To Use



1. Remove keycap


Use the keycap puller tool to clamp on a keycap and pull upwards to detach keycap from switch. Sometimes the switch may come out as well if the keycap is secured tightly on switch, which is normal. For longer keys such as the space bar, always clamp and remove from the MIDDLE of the keycap.



2. Remove Switch

Use the puller to push in the two tabs located on the top and bottom side of the switch. Once they are pushed in, pull upwards to remove switch from keyboard case.


Warning : It is very easy to scratch your keyboard case with this tool, so take caution when removing switches!



3. Insert Switch

When inserting a new switch, align switch to holes on the keyboard, and insert straight down. There should be minimal resistance and the switch should pop into the frame of the keyboard. It is recommended at this time to have a notepad ready on your PC, open it and make sure the switch works when you press it. If the switch does not light up, or the key doesn't show up on your PC when you press it, then the switch was not inserted properly. Remove switch, and make sure pins are straight then insert again.

Note : It is safe to swap switches while your keyboard is plugged in to your PC.



4. Insert keycap

Once you have confirmed the switch was properly inserted, snap back in the appropriate keycap.



INDONESIA



ATOM MK886 V2

MECHANICAL KEYBOARD

Apa yang termasuk dalam kotak

1. Keyboard Mekanik FANTECH ATOM MK886v2
2. Panduan pengguna

Persyaratan sistem

1. Sistem operasi: Windows XP/7/8/10, MAC OS
2. Satu port USB 2.0/3.0

PANDUAN PENGGUNA

Instruksi Manual

Terima kasih telah membeli Fantech ATOM MK886v2 Mechanical Keyboard. Fitur ATOM MK886v2 sakelar mekanis dan konektivitas USB kabel untuk semua petualangan bermain game Anda!

Fantech ATOM MK886v2 adalah plug and play, tidak perlu menginstal driver apa pun untuk penggunaan pertama Anda.



Spesifikasi Teknis

- Nama produk : Keyboard Mekanik FANTECH ATOM MK886v2
- Jumlah tombol : 104
- Jenis sakelar : Mekanis
- Anti-Ghosting : 25 Tombol Anti-ghosting
- Ukuran : 435(L)x127(W)x32(H)mm
- Berat : 700g


Size



Multimedia




Cara penggunaan



1. Melepas keycap


Gunakan alat penarik keycap untuk menjepit keycap dan menariknya ke atas untuk melepaskan keycap dari switch. Terkadang switch mungkin keluar juga jika keycap terpasang erat switchnya terpasang erat, dan ini normal. Untuk kunci yang lebih panjang seperti itu sebagai spasi, selalu jepit dan lepaskan dari bagian TENGAH keycap.



2. Melepas Switch

Gunakan penarik untuk mendorong kedua tab yang terletak di atas dan sisi bawah Switch. Begitu mereka dimasukkan, tarik ke atas untuk melepaskan switch dari kotak keyboard.


Peringatan : Sangat mudah untuk menggores casing keyboard anda dengan alat ini, jadi berhati-hatilah saat melepas switch!



3. Masukkan Switch

Saat memasukkan switch baru, sejajarkan switch ke lubang pada keyboard, dan masukkan lurus ke bawah. Resistansinya harus minimal dan switchnya harus masuk ke dalam bingkai keyboard. Saat ini disarankan untuk menyiapkan notepad di PC anda, buka dan pastikan switch berfungsi saat anda menekannya. Jika switch tidak menyala, atau tombol tidak muncul di PC saat Anda menekannya, maka switch tersebut tidak dimasukkan dengan benar. Lepas switch, dan pastikan pin lurus, lalu masukkan kembali.

Catatan : Aman untuk menukar switch saat keyboard anda terhubung ke PC anda.



4. Masukkan keycap

Setelah anda memastikan bahwa switch telah dimasukkan dengan benar, pasang kembali keycap pada posisi yang sesuai.