

2-in-1 Interactive Bath Seat



VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...

Pre-School

Interactive toys to develop their imagination and encourage language development

vtech Baby

Toys that will stimulate their interest in different textures, sounds and colours

I am...

...responding to colours, sounds and textures

...understanding cause and effect

...learning to touch, reach, grasp, sit-up, crawl and toddle

I want...

...to get ready for school by starting to learn the alphabet and counting

...my learning to be as fun, easy and exciting as can be

...to show my creativity with drawing and music so my whole brain develops

Electronic Learning Computers

Cool, aspirational and inspiring computers for curriculum related learning

I need...

...challenging activities that can keep pace with my growing mind

...intelligent technology that adapts to my level of learning

...National Curriculum based content to support what I'm learning at school

4-10 years

Birth-36 months

3-6 years



To learn more about this and other VTech® products, visit www.vtech.co.uk

IMPORTANT! READ CAREFULLY AND KEEP FOR FUTURE REFERENCE

WARNING - This toy is not a safety device.

WARNING - DROWNING HAZARD.

- Children have drowned while using bathing aid products.
- Children can drown in as little as 2 cm of water in a very short time.
- Always remain in contact with your child during bathing.
- Never leave your baby unattended in the bath, even for a few moments. If you need to leave the room, take the baby with you.
- DO NOT allow other children (even older) to substitute for an adult.


WARNING

- To avoid scalding by hot water, position the product in such a way to prevent your child from reaching the source of water.
- Always ensure the suction cups are well adhered to the bath tub.
- Do not use this product on a bath tub with an uneven surface.
- Use this product only when your child is able to sit unaided.
- Stop using this product when your child tries to stand up by itself.
- Check the temperature of the water surrounding the product prior to placing the child into the product. The typical water temperature for bathing a child is between 35°C and 38 °C.
- Check the stability of the product before use.
- Do not use the product if any components are broken or missing.
- Do not use replacement parts other than those approved by the manufacturer or distributor.
- Ensure the level of water is not higher than your child's navel.

INTRODUCTION

Introducing the **2-in-1 Interactive Bath Seat** by **VTech®**!

This great bath seat has a happy frog that just loves to play. Push him down for lot's of bath time fun for your little one! Features a spinning wheel and seal pourer for hours of fun bath play. Press one of the four light up button's to discover shapes, animals, numbers and to hear playful melodies. The Activity board can easily detach so the fun does not stop after bath time and can be used for floor play.



INCLUDED IN THE PACKAGE



1 Chair Back



1 Seat



1 Activity Board



4 Suction Cups



1 Seal



1 Frog

- Parent's Guide

WARNING

All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy, and should be discarded for your child's safety.


NOTE

Please save this Parent's Guide as it contains important information.

GETTING STARTED

BATTERY REMOVAL AND INSTALLATION

1. Make sure the unit is turned OFF.
2. Locate the battery cover on the back of the unit. Use a screwdriver to loosen the screw. Then remove the cover.
3. If used batteries are present, remove these batteries from the unit by pulling up on one end of each battery.
4. Install 2 new AA (AM-3/LR6) batteries following the diagram inside the battery box. (For best performance, alkaline batteries or fully charged Ni-MH rechargeable batteries are recommended).
5. Replace the battery cover and tighten the screw to secure.



WARNING:

Adult assembly required for battery installation.
Keep batteries out of reach of children.

IMPORTANT: BATTERY INFORMATION

- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.
- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.

RECHARGEABLE BATTERIES:

- Remove rechargeable batteries from the toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.

Disposal of batteries and product



The crossed-out wheellie bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.

The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in the Batteries and Accumulators Regulation.



The solid bar indicates that the product was placed on the market after 13th August, 2005.

Help protect the environment by disposing of your product or batteries responsibly.

VTech® cares for the planet.

Care for the environment and give your toy a second life by disposing of it at a small electricals collection point so all its materials can be recycled.

In the UK:

Visit www.recyclenow.com to see a list of collection points near you.

In Australia & New Zealand:



Check with you local council for kerbside collections.

ASSEMBLY INSTRUCTIONS

CAUTION:

TO ENSURE YOUR CHILD'S SAFETY, THIS PRODUCT MUST BE ASSEMBLED BY AN ADULT.

1. Attach the suction cups by pushing them firmly into the 4 holes on the underside of the seat. Please adjust the suction cups according to requirement and ensure the cups are attached securely. Once the suction cups have been attached they cannot be removed again.
2. Attach the chair back by pushing it into the holes on either side of the seat, press gently until you hear it click into place. Please ensure the seat back is attached securely. Once the seat back has been attached, it cannot be removed again.
3. Attach the frog by placing it into the centre of the activity board. Press gently until you hear it click into place. Please ensure the frog is attached securely to the activity board, once the frog has been attached, it cannot be removed again.
4. To attach the activity board turn the release lock located on the bottom of the seat. Insert the board onto the lock, push down, then release the lock. To remove the activity board turn the lock again to release, then pull the activity board away from the seat.



Note : Once the bath seat is attached to the bath, loosen the suction cups before attempting to remove.



PRODUCT FEATURES

1. ON/OFF/VOLUME CONTROL SWITCH

To turn the unit **ON**, slide the **ON/OFF/VOLUME CONTROL SWITCH** to the **LOW VOLUME**  or **HIGH VOLUME**  position. To turn the unit **OFF**, slide the **ON/OFF/VOLUME CONTROL SWITCH** to the **OFF**  position.




2. AUTOMATIC SHUT-OFF

To preserve battery life, the **VTech® 2-in-1 Interactive Bath Seat** will automatically power-down after approximately 30 seconds without input. The unit can be turned on again by pressing any button.

3. WARNINGS

- The batteries must be changed by an adult.
- Recommended bath length: 10 minutes.
- This toy cannot be used in salt water.
- After using this toy, do not leave it in the water for a long time.
- This toy can be operated in water only when fully assembled in accordance with the instructions.
- This is not a lifesaving device. Do not leave a child unattended while the **VTech® 2-in-1 Interactive Bath Seat** is in use.
- Never leave a child unattended or with an older child in the bathroom or in the bath, not even for one minute.

- Always check with a thermometer the temperature of the water coming from the tap before sitting the child in the bath. Toddlers have very sensitive skin and can easily get burnt if the water is too hot.
- Please keep your child away from the tap.
- Children's most vulnerable stage is 5-10 months.
- When closing the battery cover ensure that the screw is securely tightened. This will avoid any water leakage.
- Only use this unit in water between 10 and 45 degrees centigrade, Recommended bath water temperature: 37°C.
- Please keep the water depth to around 100 mm as marked on the legs of the bath seat.
- Always keep the child within arm's reach.
- During bath time stay in the room, do not answer the door or the phone, if you must leave the room for urgent reasons take your child with you.
- Please note the product does not provide any additional safety protection from water hazards or drowning.
- Correct position:



ACTIVITIES


1. Switch the **OFF/ LOW VOLUME/ HIGH VOLUME SWITCH** to **LOW VOLUME**  or **HIGH VOLUME** . You will hear a fun song and sound effects. The lights will flash with the sounds.




2. Press the **SHAPE BUTTONS** to hear sound effects, fun phrases and melodies. The lights will flash with the sounds.



3. Press the **Frog** to hear fun phrases and to see water spray out of his mouth.



4. The **Water Wheel** can be spun around using water scooped up in the **Seal**.



5. If there is no input to the **2-in-1 Interactive Bath Seat** after approximately 10 seconds you will hear a short phrase. If there is no input for another 10 seconds, you will be asked to find one of the animals. If there continues to be no input, the unit will automatically power-down.

MELODIES

1. Alphabet Song
2. A-Tisket A-Tasket
3. Sailing, Sailing
4. Aiken Drum
5. Row, Row, Row Your Boat
6. Looby Loo
7. Sailor's Hornpipe
8. Skip to My Lou
9. Toyland
10. Yankee Doodle
11. Humpty Dumpty
12. Incy Wincy Spider
13. Mulberry Bush
14. One Man Went to Mow a Meadow
15. Teddy Bears' Picnic

SONG LYRICS

SONG 1

Splash and sing, let's get clean,
Splash, wash, splash and wash,
having fun and washing,
We are getting clean,
wash, wash, washing, hip hip hooray!

SONG 2

Scrub-a-dub-dub your arms,
Scrub-a-dub-dub your feet.

SONG 3

I'm a frog that likes to singing,
won't you sing along with me.
Ribbit ribbit ribbit ribbit...

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat sources.
3. Remove the batteries if the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.
5. When taking a bath, the speaker may fill up with water temporarily and the volume of the product may decrease. Allow the water to drain away from the speaker or keep the speaker away from the water to recover its sound level.

TROUBLESHOOTING

If for some reason the unit stops working or malfunctions, please follow these steps:

1. Turn the unit **Off**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit sit for a few minutes, then replace the batteries.
4. Turn the unit **On**. The unit should now be ready to play with again.
5. If the unit is not working properly, install a brand new set of batteries.

If the problem persists, please contact our Consumer Services Department, and a service representative will be happy to help you.

CONSUMER SERVICES

Creating and developing **VTech®** products is accompanied by a responsibility that we at **VTech®** take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department with any problems and/or suggestions that you might have. A service representative will be happy to help you.

UK Customers:

Phone: 0330 678 0149 (from UK) or +44 330 678 0149 (outside UK)
Website: www.vtech.co.uk/support

Australian Customers:

Phone: 1800 862 155
Website: support.vtech.com.au

NZ Customers:

Phone: 0800 400 785
Website: support.vtech.com.au

PRODUCT WARRANTY/ CONSUMER GUARANTEES

UK Customers:

Read our complete warranty policy online at vtech.co.uk/warranty.

Australian Customers:

**VTECH ELECTRONICS (AUSTRALIA) PTY LIMITED –
CONSUMER GUARANTEES**

Under the Australian Consumer Law, a number of consumer guarantees apply to goods and services supplied by VTech Electronics (Australia) Pty Limited. Please refer to vtech.com.au/consumerguarantees for further information.

**Visit our website for more
information about our products,
downloads, resources and more.**

www.vtech.co.uk
www.vtech.com.au

