

# VC-TR41 – Setting Guide for Zoom Presenter Focus

## Overview

This guide explains how to configure the Lumens VC-TR41 camera for use with Zoom's Presenter Focus mode.

## Compatible Firmware


*VC-TR41: VUF105 or above*

## Connection method

1. Download the Zoom Room Controller app on a tablet.
2. Pair the controller with the computer connecting with a VC-TR41 camera by entering the code shown on the computer.





3. In the menu, select the Camera Control button to enter the control page.



4. On the control page, you can control the camera's PTZ movement and activate its tracking function by pressing the Presenter Focus button.



5. On the VC-TR41's webpage, there are different tracking modes available. The desired tracking mode should be selected beforehand, before pressing the Presenter Focus button on Room zoom controller.



### Three different modes for Presenter Focus

Zoom Presenter Mode for Presenter Focus	Lumens Tracking Mode
Free Zone Tracking	Everywhere Tracking
Area Tracking	Everywhere Tracking (Zone-based)
Content Tracking	Partition Tracking


#### a. Free Zone Tracking (Choose Everywhere Tracking mode in VC-TR41 webpage)

Camera track any target within the field.



#### b. Area Tracking (Choose Everywhere Tracking mode then draw a tracking zone)

The camera tracks only within the drawn zone in the panoramic scene when a target enters.



#### c. Content Tracking (Choose Partition Tracking mode in VC-TR41 webpage)

Camera will move to capture the specific preserved scene when a target enters the drawn zone.

