




Original	Recharge
	 Power
	 Setup / OPT /
	 Eject / Surround
	 Sound / Title
	 Menu / Home
	 Shift + Goto / Text /
	 Display / Media
	 Mute / Dimmer
	 Subtitle / EQ
	 Audio / Lang I/II
	 Info / Angle
	 Play / Slow
	 Up
	 Stop / Hold
	 Left
	 OK
	 Right

Original	Recharge
	 << / Tune-
	 Down
	 >> / Tune+
	 I<< / Preset-
	 AV / Input / RDS
	 Pause / Step / Freeze
	 >>I / Preset+
	 Zoom / Size
	 TV/Radio /
	 Green / APP / Repeat
	 Back / Return
	 1
	 2
	 3
	 Yellow / YouTube / Repeat
	 4
	 5



