

US UK

Dear user

Thank you for choosing REDRAGON product. To protect your rights and for better customer service, please read the following warranty rules carefully.

1. Within 18 months of purchase date, repair is guaranteed for failure due to electrical circuit problems. Other damages, such as disassembly, hard impacts, submersion into water, plugging into improper current or voltage, and damage caused by natural disasters such as fire, flood, or earthquake are not included.
2. Consumable parts (such as foot pads) and spare parts replacement are not included in our warranty.

1

OS Support

WinXP/Vista/Win7/Win8/Win10/Win11

How to plug in

Plug type C cable to USB cable with keyboard and PC, keyboard is plug and play, no need driver.

Key Function Introduction

FN key work with other keys

FN key work with other keys

1. FN + **[F1]** = F1
2. FN + **[F2]** = F2
3. FN + **[F3]** = F3
4. FN + **[F4]** = F4
5. FN + **[F5]** = F5
6. FN + **[F6]** = F6
7. FN + **[F7]** = F7
8. FN + **[F8]** = F8
9. FN + **[F9]** = F9
10. FN + **[F10]** = F10
11. FN + **[F11]** = F11
12. FN + **[F12]** = F12
13. FN + **[Insert]** = Insert
15. FN + **[Home]** = Home
16. FN + **[End]** = End
19. FN + **[PRTSC]** = PRTSC
20. FN + **[Volume-]** = Volume-
21. FN + **[Volume+]** = Volume+
22. FN + **[Mute]** = Mute

2

23. FN+ **[V]** =STOP
24. FN+ **[B]** =Previous track
25. FN+ **[N]** =Play/Pause
26. FN+ **[M]** =Next track
27. FN+ **[ESC]** =Press and hold for 3 seconds, back to default setting

Backlight setting

FN+ **[PGON]** : Switch backlighting effects, total 20 patterns.

FN+ **[↑ ↓]** : Adjust lighting brightness.

FN+ **[< >]** : Adjust lighting speed.

FN+ **[→]** : Switch the backlight color on keys in 8 color options.

FN+ **[←]** : Change the light running direction.

FN+ **[WIN]** : Lock Windows key and APP key, repeat to unlock.

FN+ **[TAB]** : Press FN+[TAB] to get ready for setting the backlight colors on keys. Press FN+ [TAB] again for backlighting setup, [TAB] key now is palette. Press FN+ [→] for color switching, including 8 color options and light off mode. Meanwhile 3 indicators [Num, Cap, Scroll] twinkle. Then press the desired key for colors setting, finally press FN+[TAB] key to save the setting.

FAQ

1. If the keyboard doesn't respond, please check if the keyboard's USB cable is correctly inserted into the corresponding USB port on the computer, or try another USB port on the computer.
2. If you spill liquid on the keyboard, please unplug the keyboard's USB cable from the computer immediately. Wipe off excess liquid and put the keyboard in a warm and ventilated place. Make sure the keyboard is dried naturally before the next use.



3

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help
- This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

California Proposition 65

WARNING: Risk of Cancer from [Name of one or more chemicals known to cause cancer] And Reproductive Harm From [Name of one or more chemicals known to cause reproductive toxicity] Exposure - www.P65Warnings.ca.gov

4



REDRAGON
RYZE
68 KEY WIRED MECHANICAL KEYBOARD

Mechanical Gaming Keyboard
Operating Instructions