NUX NPK-20 Soundbank Firmware Update Guide

To ensure the Soundbank update process completes successfully, please follow these steps carefully. Failure to do so may result in bricking your NUX NPK-20 or causing it to malfunction. It is also recommended that you first read this guide thoroughly before starting.

1. Getting Ready - Download and extract the Soundbank Firmware

• Download the appropriate Soundbank firmware for your operating system (Windows or macOS) from the NUX NPK-20 product page.

NUX_NPK20_SBANK_Firmware_V220517_Windows.zip is for Users on Windows. NUX_NPK20_SBANK_Firmware_V220517_macOS.zip is for Users on macOS

- Unzip the downloaded file directly to a root folder, such as C:/Desktop/ on Windows or /Users/YourUserName/Downloads on macOS. The extracted folder should contain the following files:
 - Windows: NPK20_Soundbank_20220517.bin and RPC-DFUForWin.exe
 - macOS: NPK20 Soundbank 20220517.bin and RPC-DFU 1.0.0.dmg
- 2. Connect your NUX NPK-20 to your computer and put it into DFU(Device Firmware Update) mode.
- Connect your NUX NPK-20 to your computer using a USB Type-B 2.0 cable (commonly known as a printer cable). The USB port on the NUX NPK-20 is located on the back panel.



• Press and hold both the **[DUAL/SPLIT]** and **[FUNCTION]** buttons, then press the **[POWER]** button to turn on the your NUX NPK-20 in DFU mode. Release all buttons when the screen displays:


"FIRMWARE UPDATE START READY!"






- 3. Run the Updater Utility and start the Soundbank firmware upgrade.
- Run the Updater (RPC-DFU 1.0.0.dmg for macOS or RPC-DFUForWin.exe for Windows) on your computer.


• The "Device" will show as RPC DFU(RPC) Device, which means the NPK-20 has been connected successfully.



• From the "Programming Target" dropdown menu, choose "1st Soundbank: ~~". (This step is crucial, as it specifies that you are updating the Soundbank firmware.)



• Click File..., locate the firmware file (NPK20_Soundbank_20220517.bin), then click Start Programming. Wait until the status bar reaches 100%. Do NOT unplug the USB cable or power supply during this process.



4. Complete the firmware update

- When the status bar reaches 100%, you will not be able to turn off the NPK-20 using the power button. Unplug the power supply, plug it back in, and then press the power button to turn on the NPK-20.
- The Soundbank firmware has now been updated successfully.