




Outdoor Digital Timer

SKU: HODT11C
[Instruction Manual]




Thank you for your purchase.
Please contact us if you have any questions.
We will get back to you within 24 hours.
Email: support@dewenwils.com
Please attach your Order ID so that
we can serve you better.

WARNING

TO REDUCE THE RISK OF FIRE, ELECTRICAL SHOCK OR PERSONAL INJURY, PLEASE STRICTLY FOLLOW THE INSTRUCTIONS.

- 1.SUITABLE FOR USE WITH OUTDOOR APPLIANCES – RAIN-TIGHT WHEN MOUNTED VERTICALLY WITH THE RECEPTACLE FACING DOWNWARD. NOT FOR WATER IMMERSION.STORE INDOOR WHEN NOT IN USE.**
- 2.INSTALL THE CORD AND UNIT ABOVE GROUND LEVEL AT LEAST 1.4 M WITH THE RECEPTACLE FACING DOWNWARD.**
- 3.DO NOT CONNECT ANY DEVICES WHICH EXCEED THE MAXIMUM RATINGS OF THE TIMER.**
- 4.DO NOT IMMERSE IN WATER.**
- 5.CHILDREN ARE NOT ALLOWED TO USE THE TIMER WITHOUT SUPERVISION.**
- 6.DO NOT DISASSEMBLE OR REPAIR THE PRODUCT, BUT ONLY BY AUTHORIZED SERVICE PERSONNEL.**
- 7.ALWAYS UNPLUG AND STORE INDOORS WHEN NOT IN USE.**

Product Layout



- 1.Light Sensor
Sensor will turn timer on at dusk and off at dawn.
- 2.Display
Indicates current operating mode.
- 3.Select Button
To select and switch the operating mode.

Operation Instructions

Plug the timer into a standard outlet, and then press the button on the timer to select one of the following settings:

SELECT	DESCRIPTION
F	No Power
O	Power Constantly on
1 to 9	On at dusk. Set off time for 1-9 hours. *
d	On automatically at dusk and off at dawn
1. to 9.	On immediately. Set off time for 1-9 hours.*

* Cycle repeat every 24 hours
* Once activates at dusk in the specific mode, the program cycle will be completed. Any light sources won't interfere with the program cycle.

HELPFUL TIPS

- When set to "ON", the timer will provide continual power to attached devices until the timer is switched to "OFF", or to any of the other operating modes.
- In the sensor mode, temporary light sources like headlights, porch lights and other external light sources will not interfere with the photocell function unless the external light source is on for more than 15 minutes. In that case, the timer will shut off until darkness is restored. The improvement avoids the flickering.
- Once programming activates at dusk in the 1-9 hr mode, the program cycle will complete before the timer resets. Headlights, porch lights, street lamps and other external lighting sources will not interfere with the active timer program.

Electrical Ratings

Input Voltage:

- 125V, 60Hz.

Max Power Rating:

- 125V, 60Hz, 1625W,
- 13A Resistance,
- 13A General Use,
- 1000W Tungsten,
- 500VA Electronic Ballast,
- 120Vac, 60Hz, 8.3A Ballast,
- 1/2HP.

Cord:

- SJTW 16/3 AWG.

Safety Information

Federal Communications Commission Interference Statement

This equipment has been tested and found to comply with the limits for Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

One Year Limited Warranty

DEWENWILS warrants this product to be free from defects in material and workmanship for a period of one year from the date of purchase.

Warranty is void if damage is caused by misuse or improper installation.

Email: support@dewenwils.com.

Our dedicated customer service team will get back to you within 24 hours.



Made in China