


Operation Instruction Diagram






1. Counting the number of banknotes




2. Select currency



Press the FUNC button: Change the way to check the authenticity of the banknote, MG/UV/IR.

3. Automatic and manual modes

Icon of UV/IR pattern for detecting counterfeit banknotes.




Press the A/M button: Auto mode becomes manual mode.





4. Currency denominationsetting

1) Icon for manual mode



Press the VALUE button: Set the face value of the bill to be checked.



Press VALUE again to change the face value of the banknote to be examined.

The face value of the banknote.



The face value of the banknote.



5. Cumulative counting function


The ADD icon appears 1) Press the ADD button on the screen. (3) **AUTO** USD A/M **UV MG** IR \$ ADD VALUE TOTAL > FUNC **▼VALUE BATCH**

2) This value will be added up Press the ADD key again, after counting the money the ADD icon disappears. (3) USD **AUTO** A/M UV IR ADD \$ VALUE TOTAL > FUNC DD/-SI VALUE BATCH

This value will be added up after counting the money

6. Detection mode ofmutilated currency

The DD icon appears on the screen.DD: The function of detecting residual banknotes.



Press the DD button



2)



After pressing the DD key again, the DD icon disappears.

7. "BATCH" Function



After pressing the FUNC button several times

Back to this interface

USD AUTO

UV MG IR

SVALUE

BATCH

BATCH

Back to this interface

Press the BATCH button






Press the BATCH button once more

100 sheets for one batch

4) Press the ADD+ button once



Displayed as a batch of 50 sheets



Displayed as a batch of 51 sheets



Press the DD- button three times





Displayed as a batch of 48 sheets

Please feel free to contact us by email for any product problems. The Aocktobar customer service team will respond within 24 hours and provide the best service.