

SAFARI RANGE

INSTRUCTION OF USE

To adjust back height hold back with two hands while seated and raise to desired height

To lower the back height raise back all the way to the top and release slowly


RIGHT BACK LEVER
To adjust back angle

RIGHT FRONT LEVER
To adjust seat height

700MM BLACK NYLON 6 STAR BASE WITH CASTORS

Use soft tyred castors for tiles

Use hard tyred castors for carpet



INDOOR USE ONLY

OPTIONAL ADJUSTABLE ARMS

LEFT LEVER
To adjust seat angle

X Do not use as a step ladder

DIMENSIONS: (mm)

LOW BACK	LOW BACK TO FLOOR	HIGH BACK	HIGH BACK TO FLOOR	SEAT	SEAT TO FLOOR	ARM TO FLOOR
W: 440	Lowest: 930	W: 450	Lowest: 990	W: 530	Lowest: 530	Lowest: 670
H: 400	Highest: 1140	H: 510	Highest: 1185	D: 480	Highest: 670	Highest: 880

Fabric: Chelsea bark



SA350H



SA350



SA200

Optional:



Drafting kit



Adjustable arm

Features:

Adjustable seat height
Adjustable back height (ratchet)
Adjustable seat angle
(with 3 lever mechanism only)

Adjustable back angle
Optional 2 or 3 lever mechanism
Moulded seat and back foam
Firm kidney and lumbar support

Big boy seat
700mm black nylon 6 star base
Available in local fabrics
Suitable for indoor use only

