

# SAFARI RANGE

## INSTRUCTION OF USE

To adjust back height hold back with two hands while seated and raise to desired height

To lower the back height raise back all the way to the top and release slowly


**RIGHT BACK LEVER**  
To adjust back angle

**RIGHT FRONT LEVER**  
To adjust seat height

**700MM BLACK NYLON 6 STAR BASE WITH CASTORS**

Use soft tyred castors for tiles

Use hard tyred castors for carpet



**INDOOR USE ONLY**

**OPTIONAL ADJUSTABLE ARMS**

**LEFT LEVER**  
To adjust seat angle

**X Do not use as a step ladder**

## DIMENSIONS: (mm)

LOW BACK	LOW BACK TO FLOOR	HIGH BACK	HIGH BACK TO FLOOR	SEAT	SEAT TO FLOOR	ARM TO FLOOR
W: 440	Lowest: 930	W: 450	Lowest: 990	W: 530	Lowest: 530	Lowest: 670
H: 400	Highest: 1140	H: 510	Highest: 1185	D: 480	Highest: 670	Highest: 880

*Fabric: Chelsea bark*



SA350H



SA350



SA200

Optional:



Drafting kit



Adjustable arm

## Features:

Adjustable seat height  
Adjustable back height (ratchet)  
Adjustable seat angle  
(with 3 lever mechanism only)

Adjustable back angle  
Optional 2 or 3 lever mechanism  
Moulded seat and back foam  
Firm kidney and lumbar support

Big boy seat  
700mm black nylon 6 star base  
Available in local fabrics  
Suitable for indoor use only

