






TRIXIG



Design and Quality
IKEA of Sweden



English	4
---------	---

עברית	4
-------	---

English



Caution! Recycling of built-in batteries
Built-in batteries may only be removed by
a qualified professional.

Make sure that the battery is discharged
before removal.

Use caution to avoid damaging the
battery.

Cut and isolate wires one by one to avoid
short circuit.



The crossed-out wheeled bin symbol
indicates that the item should be disposed
of separately from household waste. The
item should be handed in for recycling
in accordance with local environmental
regulations for waste disposal. By
separating a marked item from household
waste, you will help reduce the volume of
waste sent to incinerators or land-fill and
minimize any potential negative impact
on human health and the environment.
For more information, please contact your
IKEA store.

עברית



זהירות! מיחזור סוללות מובנות
הסרת סוללות מובנות תתבצע על ידי איש מקצוע
מוסמך בלבד.
יש לודא שהסוללה פרוקה לפני ההסרה.
יש לנקוט בזהירות על מנת למנוע נזק לסוללה.
יש לחתוך ולבודד את החוטים אחד אחד כדי
למנוע קצר.



סימן המיחזור מראה שיש להשליך את המוצר
בנפרד מהפסולת הביתית. יש להעביר אותו
למיחזור בהתאם לחוקים המקומיים. כשאתם
ממיינים פסולת, אתם עוזרים להפחית את כמות
האשפה המצטברת ולהקטין את ההשפעות
המוזיקות על האדם והסביבה. לקבלת מידע נוסף,
פנו לחנות איקאה.