

The instructions for use are as follows:

When receiving the product for the first time, please fully charge it first.

2. Open the charging case cover, remove the earphones, and the earphones will automatically pair.
3. Pair with other devices and turn on the wireless phone function, search for the wireless name, and then click on the link.
4. Put the earphones into the charging case to enter charging mode, and the earphones will automatically turn off.
5. The primary and secondary earphones can be connected and used separately. If the wireless earphones are not connected for a few minutes after five attempts, the device will automatically shut down

The touch function of the headphones is as follows:

1. Click once: Play/Pause Double click: Switch songs Three clicks: Adjust volume Long press to activate Siri
2. Turn off the earphones and then turn them back on to automatically reconnect to the phone;
3. The headphones have dual channel communication function, and sound is emitted from both ears;
4. Charging time is 60-90 minutes; 5. The charging voltage of the charging case is 5V/1A

## FCC Requirement

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.