



T6/T6R SMART THERMOSTAT

Registration and control with
smartphone

Quick Guide

Online Guides:



<http://hwllhome.co/eut-T6>

For help, contact:
WEB: getconnected.honeywellhome.com
PHONE: 0300 130 1299

First step is to download the Honeywell Home-app from the App store or Google Play store:


Honeywell Home-app



With the Honeywell Home-app your thermostat will be connected with your own **2,4 GHz Wi-Fi network** and registered to your account, after this you can control the thermostat remotely.

TIP Make sure you have a 2,4 GHz Wi-Fi network.
The thermostat does not work on 5 GHz networks. When in doubt, check with your Internet provider or modem settings.

- 1 Create account



Create account with your email and activate from the email you receive back.
- 2 Log on




Log on and select the thermostat you have.
- 3 Status thermostat




Press 'Yes' in the following screens.
- 4 Select



Select the thermostat (name same as displayed on thermostat-screen).
- 5 Wi-Fi network



Select your Wi-Fi network and then 'Next'.
- 6 Wi-Fi connect



Thermostat connects with your Wi-Fi network.
When successful press 'Done' Thermostat shows 'CONNECTED'
- 7 Conect



Press "Next".
- 8 Secure



Enter the code displayed on thermostat.
- 9 Configure




Select language and clock setting...
- 10 Configured




... and then 'Next'.
- 11 Complete config.




Press 'Next'.
- 12 Location



Choose a name for your location...
- 13 Name



...Then a name for the thermostat.
- 14 Register



The thermostat is now being registered to your account. This can take some minutes.
- 15 Registered



Thermostat is connected and registered, press 'Next'.
- 16 Geofence



Geofencing can be set or skipped.
- 17 Siri set up



Siri can be set up or skipped.
- 18 Completed




Registration is complete and choose 'Done'.

ANDROID

1

Create account



Create account with your email and activate from the email you receive back.

2


Log on



Log on and select the thermostat you have.

3


Thermostat



Press 'Yes' in the following screens.

4


Start Network



Press 'Next' after pressing 5 sec on the thermostat.

5


Wi-Fi network



The Android-app goes to the Wi-Fi settings. Choose 'Next'.

6

Select



Select the thermostat (name displayed on the thermostat-screen).

Press 'Dismiss' and then 'Back' of phone

7

Connect



Press "Next".

8


Secure



Enter the code displayed on thermostat.

9

Configure



Select language and clock setting...

10

Configured



... and then 'Next'.

11

Compl. config.



Press 'Next'.

12

Wi-Fi



Press 'OK' after reading the warning.

13

Select Wi-Fi



Select your Wi-Fi network and then 'Next'.



Enter your Wi-Fi password and then 'Next'.

14


Connecting



Thermostat makes connection with your Wi-Fi network and shows 'SUCCESS'

15


Location



Choose a name for your location...

16


Name



...Then a name for the thermostat.

17


Select Wi-Fi



Select your Wi-Fi network and then 'Next'.

18

Register



The thermostat is now being registered to your account. This can take some minutes.

19


Geofence



Geofencing can be set or skipped.

20

Completed



Registration is complete and choose 'Done'.



Wi-Fi® is a registered trademark of Wi-Fi Alliance®

T6-T6R-REG-ENOH 8620 NL01 1019

© 2019 Resideo Technologies, Inc.
 This product is manufactured by Resideo and its affiliates. The Honeywell Home trademark is used under license from Honeywell International Inc.
 All rights reserved.