



Original	Recharge	Original	Recharge
	Power		Power
	Setup		Setup / OPT /
	Open/Close		Eject / Surround
	Title		Sound / Title
	PBC/Menu		Menu / Home
	Goto		Shift + Text /
	Display		Display / Media
	Mute		Mute / Dimmer
	Subtitle		Subtitle / EQ
	Audio		Audio / Lang I/II
	Angle		Info / Angle
	Play		Play / Slow
	Up		Up
	Stop		Stop / Hold
	Left		Left
	Enter		OK
	Right		Right
	<<		<< / Tune-
	Down		Down
	>>		>> / Tune+
	I<<		I<< / Preset-
	Slow		AV / Input / RDS
	Pause		Pause / Step / Freeze
	>>I		>>I / Preset+
	Zoom		Zoom / Size
	Prog		TV/Radio /
	Bookmark		Green / APP / Repeat
	Return		Back / Return
	1		1
	2		2
	3		3
	C		Yellow / YouTube / Repeat
	4		4
	5		5



