

POWER BANK INSTRUCTIONS

Initial charge should be done with the Micro USB Cable, not with the solar panel option. (Charge time will vary by device)

Usage:

1. To charge the power bank, connect the battery via the micro USB to USB cable (included) to your computer, car or AC home charger. Charging time of the power bank varies between **3 to 4 hours**.
 2. Use your device's charge and sync cable (not included) to charge your device from the power bank. Press power button to activate power bank and begin charging your device.
 3. Press power button twice to turn on the LED flashlight. To turn off the LED flashlight press the power button twice.
 4. To use solar charging, simply place power bank in direct sunlight. Solar charge can take up to 24 hours of direct sunlight to charge completely.
- Make sure the power bank is fully charged before charging your device
 - LED indicators will illuminate to show battery power
 - 4 LED – 100% charged
 - 3 LED – 75% charged
 - 2 LED – 50% charged
 - 1 LED – 25% charged
 - When solar charge is active the green LED light will appear.

**THIS ITEM CONTAINS A NON-REPLACEABLE BATTERY.
WHEN THE BATTERY IS DEPLETED, PLEASE FOLLOW
YOUR LOCAL OR STATE GOVERNMENT'S GUIDELINES
FOR DISPOSAL**

CAUTION:

Use this only as intended

To prevent fire or shock hazard, do not expose this unit to rain or moisture. Do not use within a meter of any water such as swimming pools, bathtubs, or sinks.

Do not expose the batteries to excessive heat such as sunshine.

To avoid electrical shock, do not disassemble. Refer servicing to qualified personnel only.

Never insert objects of any kind, other than authorized item into the product as they may touch dangerous voltage points or short out parts that could result in fire or electrical shock.

Do not dispose of this product in fire. Refer to local country, state, and city guidelines for appropriate methods of battery disposal.

This product contains small parts that may cause choking if swallowed. Not intended for use by children under 3 years of age.

- "Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment."

- "NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help."

**Use your existing Sync & Charge Cable to power your device.
Fully charge before use. Do not leave charging overnight.**