MAX DUAL BATTERY CHARGER + BATTERY



Charge your MAX batteries using a USB port. The MAX Dual Battery Charger automatically prioritises which battery gets charged first, so you'll get a fully charged battery as quickly as possible. Includes a spare battery.

For up to 48% faster charging,¹ use it with the GoPro Supercharger (International Dual-Port Charger).²





FEATURES

- Conveniently charges 2 MAX batteries using a USB port
- Optimises charging so you'll get a fully charged battery as quickly as possible
- Allows you to charge your spare batteries while you use your camera
- Dual LED lights display charging status of both batteries
- Includes a spare 1,600-mAh lithium-ion MAX Battery
- For faster charging,¹ use it with the GoPro Supercharger (International Dual-Port Charger)²

WHAT'S INCLUDED

- · MAX Dual Battery Charger
- · MAX Battery
- USB-C Cable

COMPATIBILITY

• MAX

EU REACH SVHC Disclosure on Candidate List REACH (Registration, Evaluation, Authorisation, and Restriction of Chemicals, EC 1907/2006) is the European Union's (EU) chemical substances regulatory framework, also applicable in the UK as retained EU legislation. REACH requires GoPro to provide customers with sufficient information on Substances of Very High Concern (SVHC) contained in products in concentration above 0.1% weight by weight (w/w) to allow safe use of the product.

Substance of Very High Concern (SVHC)		
Substance Name	CAS Number	Comment
1,3 Propanesultone	1120-71-4	May be contained in main lithium-ion battery

Limited Lifetime Warranty

GoPro warrants this product for its useful life (not to exceed two years for products with electrical or electronic components) against deficiencies in material and workmanship. This LIMITED LIFETIME WARRANTY does not cover products that are improperly used, abused, altered or repaired. Products found to be defective within the warranty period will be repaired or replaced at the discretion of GoPro. GoPro reserves the right to make all determinations under this warranty. Products failing due to normal wear and tear, abuse or natural breakdown of materials over extended use and time may be repaired or replaced for a fee. For product support please, visit gopro.com/help.

Warning

Don't use the battery if it's damaged. Follow all warnings and instructions in the camera user manual.

Footnotes

¹Measured in 25°C room temperature. Charging performance may vary based on charging conditions. ²Sold separately.



