



SILKY GROOVE/SG-1C

取扱説明書

このたびはフリーザトーン製品をお買い上げ頂きまして誠にありがとうございます。末永くご使用頂くためにもご使用前にこの取扱説明書をご一読下さい。

本製品について

SILKY GROOVEは、自然で滑らかなサウンドが特徴のコンプレッサーです。ドライ音がゼロの強いコンプレッションが効いたエフェクト音から、ドライ音を混ぜたスピード感と芯のあるサウンドまで幅広いサウンドメイクが可能です。「DRY MIX」は、左に回し切った時がエフェクト音のみで、右に回すとドライ音が増えます。ノブが12時の位置でエフェクト音とドライ音の割合がほぼ1:1となります。右に回し切った状態でドライ音100%にはなりません。「SUSTAIN」は、コンプレッサーのかかりの強さを調整します。右に回すとかかりが強くなります。「ATTACK」は、アタック音を調整します。左に回すとアタック音をより抑えるように動作し、右に回すとアタック音を抑える動作が弱くなります。「LEVEL」は、エフェクトON時の出力レベルを調整します。バイパス時にも音痩せからギター信号を守るフリーザトーン独自のHTS (Holistic Tonal Solution) 回路を搭載しています。

本機のLEDは、エフェクトのON/OFF状態を表示するだけでなく、バッテリーの電圧を監視する機能を持っています。バッテリーの電圧が約6V以下になるとLEDが消灯しはじめます。この状態でもエフェクト音は出力しますが、本機の性能を十分に発揮させるためにバッテリーの交換をお奨めいたします。

*本機にバッテリーは添付されておりません。ご使用になる際は別途ご用意ください。

取扱上の注意

アンプ等スピーカーがつながっている機器の電源を入れた状態で、本機の入出力ジャックの抜き差しをしないでください。ノイズが発生し、スピーカーを痛める可能性があります。故障や異常が生じた場合はただちに使用を中止しお買い上げ店または当社までご相談ください。長時間、本機を使用しない場合はバッテリーの液漏れを防ぐためにバッテリーを取り出して保存してください。電池の電圧が低下すると、出力レベルが低下したり、音が出なくなったりします。このような場合は、新しい電池と交換してください。

主な仕様

- 入力インピーダンス: 500kΩ以上
- 出力負荷インピーダンス: 10kΩ以上
- コントロール: SUSTAIN, ATTACK, DRY MIX, LEVEL
- 端子: 1/4インチ標準フォーン・ジャック(入力、出力)、DC9V入力ジャック(ACアダプター接続用)
- 電源: DC9V電池 (9V形006P型)、ACアダプター
- 消費電流: 7mA
- サイズ: 72(W) × 115(D) × 50(H)mm (フットスイッチやジャック等の突起物含む)
- 重量: 約230g(電池含まず)
- 付属品: 保証書、取扱説明書、ゴム足×4個

※規格および外観は改良のため予告なく変更する場合があります。



SILKY GROOVE/SG-1C

User's Guide

Thank you for choosing a Free The Tone product. Please read this user's manual thoroughly to ensure that you'll benefit fully from the advanced features, performance, and reliability your Free The Tone product is designed to provide.

About the Product

The SILKY GROOVE is a compressor featuring a natural and smooth sound. This unit can provide you with a broad range of sound making from heavily compressed effect sound without dry signal to fast and strong tone composed mostly of dry sound. Setting the DRY MIX knob to the leftmost position, the unit outputs the effect sound only. Turning the knob clockwise increases the dry sound. When the knob is at the 12 o'clock position, the proportion of the effect to dry sounds becomes nearly 1:1. Please note that turning the knob fully clockwise does not make the dry sound 100%. The SUSTAIN knob adjusts the depth of the compression. Turning the knob clockwise makes the compression deeper. The ATTACK knob sets the attack of the sound. By turning the knob counterclockwise, the unit operates to suppress the attack sound more strongly and turning it clockwise makes this suppression weaker. The LEVEL knob changes the output level when the effect is turned on. The SILKY GROOVE is also equipped with FREE THE TONE's original HTS (Holistic Tonal Solution) circuit that protects the bypassed guitar signal from becoming too thin or losing tonality.

The LED indicator on this unit functions not only to show the effect on/off status but also to monitor the battery voltage. When the voltage becomes lower than about 6 volts, the LED starts to dim. Although effect sound is still output in this state, we recommend to replace the battery with a new one to keep full performance of this product.

NOTE: No battery is shipped with this package. Please prepare a suitable one separately.

Precautions

Inserting or removing a plug from the input jack while the unit's output is connected to an amplifier/speakers that is turned on can cause noise that can damage the speakers. If the unit malfunctions or behaves abnormally, cease operation immediately and refer the problem to the supplier. If the unit will not be used for an extended period of time, remove the battery to prevent damage due to chemical leakage from the battery. When the battery voltage drops too low for proper operation the effect sound may become weak, the output level may drop, or no output will be produced at all. Be sure to replace the battery as soon as possible if such symptoms occur.

Main Specification

- Input impedance: min. 500kΩ
- Output load impedance: min. 10kΩ
- Controls: SUSTAIN, ATTACK, DRY MIX, LEVEL
- Terminals: 2 x 1/4" standard phone jacks (input, output), DC9V input jack (for AC adapter connection)
- Power supply: 9-volt PP3 battery, AC adapter
- Current consumption: 7 mA
- Dimensions (W x D x H): 72 x 115 x 50 mm (incl. protuberances such as footswitches, jacks, etc.)
- Weight: approx. 230 g (excl. accessories)
- Accessories: Warranty card, manual, 4 x rubber feet

Specifications and appearance are subject to change for improvement without prior notice.