


## Installation Guide


### AMB 162, AMB 182

1




2


HRB 3 / HRE 3




HRB 4 / HRE 4




HFE 3



3




4




# Installation Guide      AMB 162, AMB 182


5





**Code No.:**  
082H0013, 082H0014, 082H0018, 082H0021




**Code No.:**  
082H0010, 082H0011, 082H0012, 082H0015,  
082H0017, 082H0019, 082H0020



**Code No.:**  
082H0016, 082H0023



6



## Installation Guide      AMB 162, AMB 182

---

---