



| Original                                                                                    | Recharge                                                                                   | Original                                                                                        | Recharge                                                                                    |
|---------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------|
|  Power     |  Power    |  CH.List     |  List    |
|  Source    |  AV       |  P+          |  Ch +    |
|  1         |  1        |  P-          |  Ch -    |
|  2         |  2        |  Menu        |  Menu    |
|  3         |  3        |  Smart Hub   |  Smart   |
|  4         |  4        |  Guide       |  Guide   |
|  5         |  5        |  Tools       |  Options |
|  6         |  6        |  Info        |  Info    |
|  7         |  7        |  Return/Back |  Back    |
|  8        |  8       |  Exit       |  Exit   |
|  9       |  9      |  Up        |  Up    |
|  0       |  0      |  Down      |  Down  |
|  TTX/MIX |  Text   |  Right     |  Right |
|  PRE-CH  |  Pre Ch |  Left      |  Left  |
|  Vol+    |  Vol +  |  OK        |  Ok    |
|  Vol-    |  Vol -  |  Red       |  Red   |
|  Mute    |  Mute   |  Green     |  Green |



