WFL001 BO551W2E 说明书

展开尺寸: 720*42mm

成型尺寸: 80*42mm

颜色: 1C+1C

材质: 105G双铜

42mm

工艺:折叠,左右9等份风琴折,封面朝外

环保认证要求 需符合RoHS环保要求 需符合RoHS和REACH环保要求 非纸质类

备注:请按图纸要求做边上带弧度的风琴折说明书

720mm 80mm POWER ON: PLACE THE EARBUDS IN THE CASE, CLOSE IT, THEN OPEN I TO PAIR YOUR HYPHEN ARIA WITH MORE THAN ONE DEVICE, FOR THE FIRST TIME: TURN OFF THE BLUETOOTH ON ANY ALREADY PAIRED DEVICE. OPEN THE CASE, THE EARBUS WILL GO INTO PARING MODE, SO YOU CAN NOW PAIR THE EARBUOS WITH THE NEW DEVICE. INSIDE THE PACKAGING, YOU CAN FIND THREE DIFFERENT SIZES OF SOFT SILICOME GRAVITY HOOKS" SITTABLE FOR ALL SHAPES OF EARS. DISCOVER THE BEST FIT FOR YOU BY SWITCHING THE HOOKS AND TRYING ALL DIFFERENT SIZES. CHARGING CABLE ONE TAP → PLAY/PAUSE / ANSWER CALL STATUS LED BEHAVIOR STATUS LED BEHAVIOR INSERT THE EARBUDS INTO THE CHARGING CASE AND CLOSE THE CASE. THE EARBUDS ARE CHARGING WHEN THEIR LED IS BREATHING WHITE EVERY 4 SECONDS. WHEN THE EARBUDS ARE IN THE CASE AND THEIR LED IS OFF, THEY ARE FULLY CHARGED. POWER OFF: PUT THE EARBUDS BACK INTO THE CASE AND CLOSE IT. THE EARBUDS WILL PULSE DRANGE TWICE TO INDICATE THEY ARE POWERING OFF. YOU CANNOT TURN OFF THE EARBUDS WITHOUT THE CASE ●● DOUBLE TAP → NEXT SONG / HANG UP A CAL USB-C BATTERY 0-30%(CHARGING) ORANGE LED BREATHING (EVERY 4 SEC) POWER ON AFTER THEY ARE PAIRED WITH MORE THAN ONE DEVICE, THEY WILL AUTOMATICALLY CONNECT TO THE LAST DEVICE USED. ••• TRIPLE TAP → PREVIOUS SONG / SWITCH CALL THE TIPS COME IN SIZES L. M. S. THEY ARE MARKED L FOR LEFT, R FOR RIGHT. BATTERY 31-100% (CHARGING) WHITE LED BREATHING (EVERY 4 SEC) POWER OFF ORANGE LED BREATHES TWICE, THEN OFF 1. WITH THE EARBUDS IN THE CASE, OPEN THE COVER TO START PAIRING, THE EARBUDS WILL START BREATHING WHITE. 2. OPEN YOUR DEVICE'S BLUETOOTH SETTIMES AND SELECT "HYPHEN ARIA" TO PAIR THE EARBUDS WITH YOUR DEVICE. 3. WHEN THE LEGS STOP BREATHING, THE EARBUDS ARE PAIRED WITH YOUR DEVICE. YOU CAN NOW TAKE THEM OUT OF THE CASE AND USE THEM. IN ORDER TO SWITCH CONNECTION TO ANOTHER DEVICE, SIMPLY SELECT THE EARBUDS FROM THE DESIRED DEVICE'S BLUETOOTH SETTINGS. SLIDE UP + VOLUME UP (ONE STEP) THE CASE CAN BE CHARGED USING A TYPE-C CABLE (INCLUDED), OR USING A COMPATIBLE WIRELESS CHARGER. BY DEFAULT, THE SIZE M IS ON THE EARBUDS, YOU CAN FIND THE SIZE S AND L INSIDE THE EARTIPS POUCH. PAIRING MODE BATTERY FULLY CHARGED WHITE LED STAYS ON SLIDE UP + HOLD → VOLUME UP AUTOMATICALLY THE CASE IS CHARGING WHEN THE LED BREATHES EVERY 4 SECONDS: PLACE BOTH EARBUDS IN THE CHARGING CASE, LEAVING THE CASE'S COVER OPEN. NOTE: SELECTING THE CORRECT SIZE OF EARTIPS FOR YOU IS ESSENTIAL FOR OPTIMAL COMFORT AND SOUND QUALITY. GRAVITY HOOK™ EAR TIPS - ORANGE (BATTERY LEVEL BETWEEN 1-30%) - WHITE (BATTERY LEVEL BETWEEN 31-100%) BATTERY 0-30% (OPEN/CLOSE) ORANGE LED ON FOR 10 SEC, THEN OFF SLIDE DOWN . VOLUME DOWN (ONE STEP) PRESS AND HOLD THE CASE'S RESET BUTTON FOR 5 SEC, UNTIL BOTH EARBUDS START FLASHING WHITE. AFTER THE FIRST PAIRING, THE EARBUDS WILL CONNECT AUTOMATICALL TO YOUR DEVICE, AS SOON AS YOU OPEN THE CASE, IF YOUR DEVICE' BLUETOOTH IS ON. WHEN THE CASE IS FULLY CHARGED, THE WHITE LED WILL STOP BREATHING AND STAY ON, WHITE. BATTERY 31-100% (OPEN/CLOSE) WHITE LED ON FOR 10 SEC, THEN OFF SLIDE DOWN + HOLD - VOLUME DOWN AUTOMATICALL CHARGING (IN CASE) • ■ ONE TAP + LONG PRESS 1S → VOICE ASSISTANT IMPORTANT: TO PREVENT PREMATURE BATTERY DEGRADATION, MAKE SURE TO CHARGE BOTH THE CASE AND THE EARBUDS AT LEAST ONCE EVERY 3 MONTHS TO USE A SINGLE EARBUD, JUST REMOVE THE ONE YOU WANT TO USE FROM THE CASE AND LEAVE THE OTHER EARBUD INSIDE. FULLY CHARGED (IN CASE) LED OFF

FEATURES

AIR CONDUCTION TECHNOLOGY DYNAMIC BASS ENHANCEMENT™ PATENTED GRAVITY HOOK" IN 3 SIZES DUAL MIC ENVIRONMENTAL NOISE CANCELLING 14.8MM DRIVER FOR RICH SOUND QUALITY FULL TOUCH & SLIDE CONTROL IPX4 WATER RESISTANCE

SPECIFICATIONS

IMPEDANCE: 16±15% SUPPORTS: AAC, SBC, A2DP 1.3, AVRCP 1.6, HFP 1.7 FREQUENCY RESPONSE: 200HZ-20KHZ DISTORTION: ±30B AT 1KHZ BATTERY CAPACITY:
EARBUDS: 3.70, 78MAH
CHARGING CASE: 3.70, 558MAH
WURKING ITME: UP TO 428 MIN
PHONE 318M
GHARGING IIME:

DISTURTION: 2585
TRANSMISSION DISTANCE:
PLAY MUSIC STATE: EARBUDS AND
PHONE 318M
ON CALLS: EARBUDS AND PHONE >18M CHARGING TIME:
EARBUDS: 120 MIN
CHARGING CASE: 180 MIN
CHARGING CASE: 180 MIN
MAIN MATERIAL: ABS
DOUBLE CHANNEL SUPPORT: YES

SAFETY INFORMATION

 LISTENING AT HIGH VOLUME FOR LONG PERIODS OF TIME CAN CAUSE HEARING DAMAGE.
 DO NOT INSERT THE EARBUDS TOO DEEP INTO YOUR EARS, AND NEVER INSERT THEM WITHOUT EARTIES.

- KEEP THE PRODUCT, ACCESSORIES, AND PACKAGING PARTS DUT OF THE REACH OF CHILDREN AND PETS TO PREVENT ACCIDENTS OR CHOKING HAZARDS.

- USING FARBUS LIMITS VOUR ABILITY TO HEAR SOURD AROUND YOU, REGARDLESS OF THE LISTISHING VOLUME, PLEASE BE CAUTIOUS WHEN USING EARBURS.

- ON NOT USE THESE EARBUS WHEN OPERATING A MOTOR VEHICLE, A DELYCLE, A MACHINERY OR WHEN YOUR INABILITY TO HEAR OUTSIDE SOUNDS MAY PRESENT A DANGER TO YOURSELF OR TO DITHERS. TO DITHERS.

- HYPHEN META ORE SWEAT AND SPLASHING RESISTANT, SWEAT AND SPLASHING RESISTANCE ARE.

NOT PERMANENT CONDITIONS, AND RESISTANCE MIGHT DECREASE AS A RESULT OF NORMAL WEAR.

DO NOT ATTEMPT TO CHARGE HYPHEN ARIZA WHEN THEY ARE MET, THE CHARGING CASE IS NOT SWEAT OR WATER-RESISTANT.

NOTE

- CONNECT THE EQUIPMENT INTO AN OUTLET ON A CIRCUIT DIFFERENT FROM THA TO WHICH THE RECEIVER IS CONNECTED. - CONSULT THE DEALER OR AN EXPERIENCED RADIO/TV TECHNICIAN FOR HELP CHANGES OR MODIFICATIONS NOT EXPRESSLY APPROVED BY THE PARTY RESPONSIBLE FOR COMPLIANCE COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS:

(1) THIS DEVICE MAY NOT CAUSE HAMMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESTREED OPERATION.

PREVENTING DAMAGES TO THE PRODUCT AND MALFUNCTIONS

ALMAYS KEEP THE PRODUCT DRY AND DO NOT EXPOSE IT TO EXTREME TEMPERATURES TO AUGID CORROSION OR DEFORMATION. CLEAN THE PRODUCT ONLY WITH A SOFT, DRY CLOTH.

INTENDED USE / LIABILITY

THIS EARBUDS ARE DESIGNED FOR USE WITH PORTABLE DEVICES AND HI-FI SYSTEMS.

IT IS CONSIDERED IMPROPER USE WHEN THIS PRODUCT IS USED FOR ANY
APPLICATIONS NOT SPECIFIED IN THE ASSOCIATED PRODUCT GUIDES.

THE COMPANY DOES NOT ACCEPT LIABILITY FOR DAMAGE ARISING FROM ABUSE OR
MISUSE OF THIS PRODUCT.

NEED HELP?

OUR CUSTOMER SUPPORT TEAM IS ALWAYS AVAILABLE FOR YOU.

WWW.ROLLINGSQUARE.SUPPORT

ROLLINGSDUARE® AND HYPHEN® ARE OWNED AND OPERATED BY FERRARIS GROUP SAGL, A COMPANY WITH ITS MAIN OFFICES IN CORSO SAN GOTTARDO 99, CHIASSO 6830, SWITZERLAND:

ROLLINGSQUARE®

SCAN TO GET STARTED







USER GUIDE

