


INSTRUCTION MANUAL

LUMERI X350



Note: As the product system is updated from time to time, the specific operation content is based on the actual situation.
This product is only suitable for projections of images & video, and may not be used for room lighting.



●Important Safeguards

1. Please read the manual carefully before operating projector. To ensure stable power supply, please use standard power cable.
2. Please use the power supply and cable indicated on the rating label. The projector should be kept away from cloths, sofas and anything that may block the ventilation scoop. Please keep the unit away from flammable and explosive materials.
3. Please do not disassemble the unit yourself as this will invalidate the warranty service. To protect your eyes, do not stare directly at the lens when the projector is on. The projector must be kept away from water and any other liquids.
4. To prevent electric shock, please keep the projector out of the rain and away from moisture. It is recommended to switch off the projector after it has run for 6 hours non-stop. Please use the original foam and other cushioning materials when transporting the projector.
5. If the projector does not work, please contact the authorized service agent.

●Accessories List

AV signal cable ×1
Remote control ×1
Power cable ×1
User manual ×1

●Projector Overview



- 1.Lens
- 2.IR for remote control
- 3.Hot winds output ventilation
- 4.USB1 port
- 5.3.5mm port for audio output
- 6.AV port
- 7.HDMI 1 port
- 8.HDMI 2 port
- 9.USB 2 port
- 10.Speaker


- 11.VGA port
- 12.IR for remote control
- 13. Signal lights
- 14. Power Button
- 15. Return
- 16. Menu
- 17. Source
- 18. OK Key
- 19. Arrow keys
- 20. Keystone correction
- 21. Focusing

●Specifiction


Model	LCD projector	Image system	LCD
Lamp	LED 50,000 HOURS	Native resolution	1280×720,support 1080P
Language	English, 23 language	Input voltage	AC100V-240V
Brightness	3500 lumens	Size	215×185×87mm
Aspect Ratio	16:9 / 4:3	Working temp	0~35℃
Weight	1.5 KG	Input voltage	HDMI / USB / VGA / AV
Operation mode	Manual / Remote control	Output	Headphone

●Multimedia Supported Files


Image Format	JPG/PNG/BMP/JPEG
Video Format	MP4/MKV/MOV/WMV/RMVB/RM/AVI/FLV/TRP/VOB/3GP/DIVX/TP/TS/MPG/M2TS/F4V/DAT
Audio Format	MP3/AAC/WAV/FLAC/WMA/M4A
File Format	TXT

 The projector does not support Dolby audio decoding.

●Remote control




●Focus / Keystone Correction



I. Image focus
Place the projector lens perpendicular to the projection screen or curtain wall, and rotate the lens to adjust until the image is clear, that is, complete the image focus. During the focusing process, you can play the program or recall the menu image of the product to match the focus adjustment.


II. Keystone correction
Please turn the trapezoidal adjustment dial until the image is displayed normally.
Note: The projector has only mechanical trapezoidal correction in the vertical direction and there is no horizontal correction. Make sure the projector is level with the projected image.



●How to set the menu


Select Setup in the main interface, first press left/right keys to select sub-menu, second setup the mode you need, finally press OK key to confirm.

- Submenu:**
PICTURE: Picture Mode \ Contrast \ Brightness \ Color \ Tint \ Sharpness \ Focus \ Color Temperature \ Noise Reduction.
SOUND: Sound Mode \ Treble \ Bass.
OPTION: OSD Language \ Aspect Ratio \ Projection Mode \ Factory Reset \ Software Upgrade \ Version.




●How to Select Source

Step 1: Select the source you want in the main interface, such as HDMI, AV, etc.
Step 2: Press OK button on the remote control to enter corresponding source interface.



●How to play multimedia

Step 1: Select "USB" in the main interface.
Step 2: After entering the interface, select the file you want to play.



●Standard setting

Refer to the data in the table below to place the projector away from the projection screen according to the preset graphic size. When installing, place the projector on a solid, stable countertop or use a hanger to hoist it to the ceiling. The airframe should be well ventilated. Do not cover or block the vents. There should be no obstructions within 30cm of the vents.

Aspect ratio	16:9
Picture size (inch)	Projection distance (m)
50 "	1.41
70 "	1.97
100 "	2.81
120 "	3.37

Note: The above data is for reference only, please refer to the physical measurement.

This product is only suitable for projections of images & video, and may not be used for room lighting.



The terms HDMI and HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc. in the United States and other countries.