


# INSTRUCTION MANUAL



English

### 1. Important Safeguards

1.1 Please read the manual carefully before operating projector. To ensure stable power supply, please use standard power cord.


1.2 Please use the power supply and cable indicated on the rating label. The projector should be kept away from cloths, sofas and anything that may block the ventilation scope. Please keep the unit away from flammable and explosive materials.

1.3 Please do not disassemble the unit yourself as this will invalidate the warranty service. To protect your eyes, do not stare directly at the lens when the projector is on. The projector must be kept away from water and any other liquids.

1.4 To prevent electric shock, please keep the projector out of the rain and away from moisture. It is recommended to switch off the projector after it has run for 6 hours non-stop. Please use the original foam and other cushioning materials when transporting the projector.


1.5 If the projector does not work, please contact the authorized service agent.

### 2. Structural Diagram




1. VGA for laptop or computer input  
2. IR for remote control  
3. Headphone port for audio output  
4. AV port for normal signal input  
5. USB port for multimedia play  
6. OUT 5V  
7. HDMI port for HD signal input

### 3. Panel Functions




1. Source: choose the input signal source  
2. Menu: operate multiple functions  
3. Return  
4. Signal lights  
5. Up: move up  
6. Power Button: power on or off  
7. Left: move left or volume down  
8. Down: move down  
9. Right: move right or volume up

### 4. Function Operation



1. Power  
2. Aspect ratio  
3. Arrow keys  
4. Homepage  
5. Menu  
6. Volume Down  
7. Setting  
8. Screen-Flip  
9. Source  
10. Enter  
11. Exit  
12. Volume Up  
13. Mute

### 5. Focus/Keystone



1. Focus  
2. Keystone

### 6. Miracast Connection

#### 6.1 Wi-Fi setup

Projector Wi-Fi connection: Select setup—network setup—wireless network—searching network under home page, select your Wi-Fi and confirm the connection. Mobile device Wi-Fi connection: Connect your mobile device to the same Wi-Fi as the projector.

| Network | Projector     | Advanced      | Information   |
|---------|---------------|---------------|---------------|
| WiFi    | 192.168.1.100 | 192.168.1.100 | 192.168.1.100 |


#### 6.2 Miracast

Select android miracast under the home page on projector, turn on the display setting or multi-screen interaction on your android phone, select the corresponding projector name, then enter to the multi-screen interaction.

Notice:  
\*Different android devices have different access of multi-screen interaction. Please refer to the instructions of android devices for details.  
\*Please make sure the mobile phone and the projector are connected with the same Wi-Fi.  
\*Different projects show different names, please consider the actual situation.

### 6.4 DUNA

Enter into DUNA mode on the projector, and access the mobile devices video App then go to the TV screen mode and select the corresponding projector ID, you will get the screen image on the projector.



1. Select the DUNA mode on the projector.  
2. Select the DUNA mode on the mobile device.

### 6.5 Bluetooth Setup

If you want to connect a Bluetooth device, you can go to setup—Bluetooth—Scan to select your Bluetooth device, and confirm the connection.


\*You have to set your Bluetooth device in pair mode firstly before scan.

| Network   | Bluetooth     | Projector     | Advanced      | Information   |
|-----------|---------------|---------------|---------------|---------------|
| Bluetooth | 192.168.1.100 | 192.168.1.100 | 192.168.1.100 | 192.168.1.100 |

### 6.6 Digital Zoom

You can change the picture size by adjusting Digital Zoom.

\*Digital Zoom can be adjusted only while using HDMI/VGA/AV/Media, not iOS cast/Miracast.



76