




BTR1

QUICK GUIDE



ON/OFF

CONTROLS DESCRIPTION



SWITCH ON



Press together for 3 sec.



Beep



Flashes

SWITCH OFF



Press together for 3 sec.




Jingle



Flashes

PAIRINGS

CONTROLS DESCRIPTION



Note: the audio source paired to **VOL+** button (Music or navigator's indications) remains in background to the intercom communication opened between two people.

PAIRINGS

PHONE, GPS, TFT PAIRING

Status: device on



Press Vol+ 5 sec.



Beep



Flashes



Select BTR1 in your phone, GPS or TFT



Beep



Confirmation (1 sec.)

Note: to pair a second device in audio mono mode, repeat the same procedure but press **Vol-**.

PAIRING WITH MIDLAND INTERCOM

Status: device on

7"



7"



Press 7 sec.
(you can press any key)



Flashes



Confirmation (1 sec.)

Press 7 sec.
(you can press any key)



Flashes



Confirmation (1 sec.)

PAIRING WITH OBI INTERCOM

Status: device on



OBI intercom
(Cardo...)

Press 7 sec.
(you can press any key)



Flashes



Confirmation (1 sec.)

Follow the **intercom pairing** procedure (see intercom's instructions)

UNIVERSAL INTERCOM PAIRING

Status: device on

7"



Press 7 sec.
(you can press any key)



Flashes



Confirmation (1 sec.)

Follow the **phone pairing** procedure (see intercom's instructions)

Attention: you can pair a maximum of 3 intercom devices (Midland, OBI or other brand), one for each button.
A new pairing on the same button overwrites the previous one.

PAIRINGS

BLUETOOTH PAIRING RESET

Status: device on



Press together 5 sec.



Voice announcement



Steady



Press together for 3 sec.



Beep



Confirmation (1 sec.)

FACTORY SETTINGS RESET

Status: device on



Press together 5 sec.



Voice announcement



Steady



Press together for 3 sec.



Beep



Confirmation (1 sec.)

INTERCOM FUNCTIONALITY

The “Intercom” communication allows you to talk to one person at a time, through any of the paired intercoms, or to talk to more than one intercom device at the same time (Conference mode).



Intercom communication one person at a time

When the intercom communication is already open to one person, first close it and only then open the Intercom communication to another person.



Conference mode

When the intercom communication already open to one person, just open the intercom to a second person without closing the first conversation. In Conference mode you can talk up to 4 people in a chain (Conference to 4). Each intercom device can have two communications open simultaneously.

Note: in the device with the Conference mode activated (intercom open to other two devices), you can however receive a phone call from the device paired to Vol+ (the music in background and the device paired to Vol- will be temporarily disconnected and will be connected again when the second intercom is closed).

INTERCOM FUNCTIONALITY

FUNCTIONS DESCRIPTION

Up button - Rider 2:

(Midland/OBI/Universal Intercom)



Control button - Rider 1

(Midland/OBI/
Universal Intercom)

Down button - Rider 3

(Midland/OBI/
Universal Intercom)

Intercom functions are accessed by pressing twice the buttons corresponding to the pairings.

OPEN/CLOSE INTERCOM AND OBI MANUALLY

	Press twice (the button corresponding to the pairing)
	Beep
	Flashes

Note: to talk with Rider 2 or Rider 3 repeat the procedure but press the buttons corresponding to the pairings.

OPEN INTERCOM BY VOICE (VOX)

	Say "Hello"
	Jingle
	Flashes
	Silent for 1 minute; intercom closes
	Beep

Note: the voice activation is possible only with the intercom paired to the **Control button-Rider 1** (VOX must be active)

TO OPEN/CLOSE UNIVERSAL INTERCOM

	Press twice (the button corresponding to the pairing)
	Beep
	Flashes

Note: to open/close the audio from **the different brand device**, use the **voice call** command (for some models it is necessary to send the voice call twice).

INTERCOM FUNCTIONALITY

TO ENABLE/DISABLE VOX (Open Intercom by voice)



Press together Control and Vol+ for 3 sec.



Voice announcement

NOISE GATE ENABLE/DISABLE (Mutes microphone in absence of voice)



Press together Control and Vol- for 3 sec.



Voice announcement

AGC ENABLE/DISABLE (volume automatic adjustment according to speed)



Press together Vol+ and Vol- for 3 sec.



Voice announcement

PHONE FUNCTIONALITY

FUNCTIONS DESCRIPTION

Play/Pause



Voice assistant
(Phone on Vol+)

Voice assistant
(Phone on Vol-)

Phone functions are accessed by pressing once on the buttons.

TO ACTIVATE VOICE ASSISTANT (no audio active)

Press once



Voice assistant
response (Google
assistant, Siri)



Give instructions



Call

Note: If your phone is paired to Vol-, use the **Down** button.

PHONE FUNCTIONALITY

ANSWERING/ENDING/REJECTING A CALL



x1

Press once to answer/end a call

3"

Press for 3 sec. to reject a call

Note: you can press any key.

MUSIC SHARE WITH PASSENGER



Select music App

Open Midland intercom (manually or by voice)



Press for 3 sec



Voice announcement

Note: it is possible to share music only with a Midland intercom (except for BTMINI model).

MUSIC



Select music App



x1

Press once Play/Pause



x1

Press once Next track



x1

Press once Previous track

Frequency (GHz)

Max power (mW)

2.402 - 2.480

100



Scan the QR code to access the support page,
update the firmware, download this pocket
guide on your smartphone .. and find all
info about BTR1, including video tutorial and
installation.

Midland World



Download Midland Connect from
App Store or Google Play

