

COMMANDÉE VOCALE OPTIONNEL

 works with Alexa

 works with Hey Google

CONFIGURATION DE LA COMMANDE VOCALE AMAZON

Assurez-vous que votre appareil Amazon Alexa est installé et configuré.

ETAPE 1: Ouvrez l'application Alexa et accédez à « Compétences ».

Recherchez et choisissez **MONSTER SMART**.

ETAPE 3: Activez la Skill et autorisez votre compte en utilisant vos informations de connexion.

REMARQUE: Utilisez les mêmes informations de connexion que vous avez utilisées pour créer votre compte Monster Smart.

À tout moment, accédez à l'application Alexa pour définir des sumoms et des pièces pour vos appareils. Vous pouvez également renommer les appareils dans l'applications Monster Smart.

En utilisant le nom RGBW Party Light Bar ou le nom que vous avez attribué à votre RGBW Party Light Bar, vous pouvez demander à votre assistant Google de contrôler votre appareil, dites simplement "Hey Alexa" et demandez "Activer ma RGBW Party Light Bar", "Définir ma RGBW Party Light Bar sur bleu", "Définir ma RGBW Party Light Bar sur 50 % de luminosité", et plus encore !

B | 1

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18

19

20

21

22

23

24

25

26

27

28

29

30

31

32

33

34

35

36

37

38

39

40

41

42

43

44

45

46

47

48

49

50

51

52

53

54

55

56

57

58

59

60

61

62

63

64

65

66

67

68

69

70

71

72

73

74

75

76

77

78

79

80

81

82

83

84

85

86

87

88

89

90

91

92

93

94

95

96

97

98

99

100

 Add to Siri

CONFIGURATION DE LA COMMANDE VOCALE GOOGLE

Assurez-vous que votre appareil Google Assistant est installé et configuré.

ETAPE 1: Ouvrez l'application Google Home, accédez à la page d'accueil et appuyez sur le bouton "+".

ETAPE 2: Cliquez sur "Configurer l'appareil".

ETAPE 3: Recherchez et choisissez **MONSTER SMART**.

ETAPE 4: Autorisez votre compte en utilisant vos informations de connexion.

REMARQUE: Utilisez les mêmes informations de connexion que vous avez utilisées pour créer votre compte Monster Smart.

À tout moment, accédez à l'application Alexa pour définir des sumoms et des pièces pour vos appareils. Vous pouvez également renommer les appareils dans l'applications Monster Smart.

En utilisant le nom RGBW Party Light Bar ou le nom que vous avez attribué à votre RGBW Party Light Bar, vous pouvez demander à votre assistant Google de contrôler votre appareil, dites simplement "Hey Alexa" et demandez "Activer ma RGBW Party Light Bar", "Définir ma RGBW Party Light Bar sur bleu", "Définir ma RGBW Party Light Bar sur 50 % de luminosité", et plus encore !

B | 1

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18

19

20

21

22

23

24

25

26

27

28

29

30

31

32

33

34

35

36

37

38

39

40

41

42

43

44

45

46

47

48

49

50

51

52

53

54

55

56

57

58

59

60

61

62

63

64

65

66

67

68

69

70

71

72

73

74

75

76

77

78

79

80

81

82

83

84

85

86

87

88

89

90

91

92

93

94

95

96

97

98

99

100

 Add to Siri

CONFIGURATION DE LA COMMANDE VOCALE SIRI

Nécessite un iPhone exécutant iOS 12 ou une version ultérieure.

ETAPE 1: Ouvrez l'application Google Home, accédez à la page d'accueil et appuyez sur le bouton "+".

ETAPE 2: Cliquez sur "Configurer l'appareil".

ETAPE 3: Recherchez et choisissez **MONSTER SMART**.

ETAPE 4: Autorisez votre compte en utilisant vos informations de connexion.

REMARQUE: Utilisez les mêmes informations de connexion que vous avez utilisées pour créer votre compte Monster Smart.

À tout moment, accédez à l'application Alexa pour définir des sumoms et des pièces pour vos appareils. Vous pouvez également renommer les appareils dans l'applications Monster Smart.

En utilisant le nom RGBW Party Light Bar ou le nom que vous avez attribué à votre RGBW Party Light Bar, vous pouvez demander à votre assistant Google de contrôler votre appareil, dites simplement "Hey Alexa" et demandez "Activer ma RGBW Party Light Bar", "Définir ma RGBW Party Light Bar sur bleu", "Définir ma RGBW Party Light Bar sur 50 % de luminosité", et plus encore !

B | 1

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18

19

20

21

22

23

24

25

26

27

28

29

30

31

32

33

34

35

36

37

38

39

40

41

42

43

44

45

46

47

48

49

50

</div



INDOOR/OUTDOOR RGBW PARTY WALLWASHER LIGHT BAR

QUICK START GUIDE
MOWA002-CAN - V2.0 05/24

GETTING STARTED

Thank you for choosing the RGBW Party Wallwasher Light Bar by Monster Smart Illuminessence. This **Quick Start Guide** will help you with setup and installation of your device.

WHAT'S IN THE BOX

- RGBW Party Wallwasher Light Bar
- Wall Mounting Accessories x4 pair
- Ground Stakes x2
- Power Cord
- Quick Start Guide

WHAT DO YOU NEED?

- Cellphone or tablet with Android™ 6.0 Marshmallow or higher / iOS 10 or higher
- Wi-Fi router with an internet connection
- Wi-Fi 2.4GHz 802.11n
- Phillips head screwdriver

Before setup, make sure your phone or tablet is connected to the **2.4GHz Wi-Fi network**. Turn on your RGBW Party Light Bar before pairing. Turn on Location and Bluetooth to quickly find nearby devices.

TIP: Do you know your Wi-Fi network name and password? Write it down now; it's hard to remember!

ANYTHING ELSE?

The power cord must be connected to a GFCI protected hooded flush type cover plate receptacle marked "Wet Location" while in use outdoors.

TIP: Save these instructions for future reference.

Input: 120V AC

SETUP COMPLETE SETUP BEFORE INSTALLATION

Remove your RGBW Party Light Bar and all components from the box.



It is recommended to first pair your device in a location close to your router BEFORE installation.

NOTE: If desired, you can operate the device with the controller and without pairing to Wi-Fi and without the app. Advanced features like color customization, scheduling, and voice control will not be available. (See "How To Use" on page 8)

STEP 1
Download the **MONSTER SMART** app from the App Store (for iPhone) or Google Play Store (for Android phones).



STEP 2
Make sure your phone or tablet is successfully connected to the **2.4GHz Wi-Fi network** that your device will be placed on and ensure that your Bluetooth is enabled.

Open the **MONSTER SMART** app and create an account by following the on-screen instructions.

NOTE: Most Smart devices only work on a 2.4GHz Wi-Fi network. Many newer home Wi-Fi networks are mixed networks that are set up to support both 2.4GHz and 5GHz. You may need to switch to AP pairing mode to connect. If you still have difficulty, contact your Internet Service Provider for assistance with 2.4GHz network setup.

STEP 3
Connect the power cord to the device and screw on the water-light locking cap until secure.

Plug the other end of the power cord to a powered wall outlet, the light should turn on. If needed press the multifunction button twice to turn off the light.

Press and hold the multifunction button for 5-6 seconds to enter pairing mode. The light will begin blinking when it has entered pairing mode and is ready to pair.

STEP 4
Confirm that the network displayed is your **2.4GHz Wi-Fi network**, then enter your Wi-Fi password and click "Confirm".

NOTE: This may take up to one minute

Once complete, your device will be connected to the network. Confirm or change the settings for your device and then click "Done". Your device is now set up and ready to use!

STEP 5
Assign the name to the device, assign to a room, and more!

You can now use the app to add voice control (see pg 10), adjust settings, create custom lighting effects, set schedules, and more!

STEP 6
Confirm the device is in pairing mode - LEDs are **RAPIDLY** blinking. In the **MONSTER SMART** app, select the "+" in the upper right corner of the home screen to add a new device.

The app will detect the nearby Wi-Fi+BLE enabled device and ask if you would like to add it. Click "Go to add".

Ensure that the device is checked and then click the "+" button.

STEP 7
This product can be placed on a table or the floor, mounted on a wall, or staked into the earth outdoors.

STEP 8
• If mounting on the wall, ensure that the mounting screws go through the holes in the feet and into a stud in the wall.
• If using indoors, use the included wall mounting brackets.
• If using outdoors, you can use the included yard stakes for added stability.
• The feet can slide left and right to align with your desired install location. Tighten each of the set screws to hold the position.

STEP 9
Once complete, your device will be connected to the network. Confirm or change the settings for your device and then click "Done". Your device is now set up and ready to use!

STEP 10
Assign the name to the device, assign to a room, and more!

You can now use the app to add voice control (see pg 10), adjust settings, create custom lighting effects, set schedules, and more!

INSTALLATION

The water-resistant RGBW Party Light Bar is perfect for adding dramatic lighting both indoors and outdoors, ideal for everyday lighting as well as fun party lighting for special events.

STEP 1
Determine where you will install the RGBW Party Light Bar. Make sure the location is still within the range of your Wi-Fi network and that it is close enough to a power source for the cord to reach without becoming a tripping hazard.

STEP 2
This product can be placed on a table or the floor, mounted on a wall, or staked into the earth outdoors.

STEP 3
• If mounting on the wall, ensure that the mounting screws go through the holes in the feet and into a stud in the wall.
• If using indoors, use the included wall mounting brackets.
• If using outdoors, you can use the included yard stakes for added stability.
• The feet can slide left and right to align with your desired install location. Tighten each of the set screws to hold the position.

STEP 4
Once complete, your device will be connected to the network. Confirm or change the settings for your device and then click "Done". Your device is now set up and ready to use!

STEP 5
Assign the name to the device, assign to a room, and more!

You can now use the app to add voice control (see pg 10), adjust settings, create custom lighting effects, set schedules, and more!

HOW TO USE

Your RGBW Party Light Bar can be easily controlled by the controller, using the **MONSTER SMART** app to access advanced and customizable lighting effects, or by using a compatible voice assistant product (see page 10).

BUTTON CONTROL

POWER: Double click = turn on/off your device
MODE: Click = change between preset colors
RESET: Press and hold = reset the device and to pair to your Wi-Fi network

GROUPING DEVICES

Your RGBW Party Light Bar is great to use individually, you can control each separately or easily group multiple lights together in the app to control them all as one. Click the "Group" button in the upper right corner and then click "Create Group" to group your devices.

STEP 1
RGBW Party Light Bar
Select device
Create Group
Group selected
Hold feedback

STEP 2
Once complete, your device will be connected to the network. Confirm or change the settings for your device and then click "Done". Your device is now set up and ready to use!

STEP 3
Assign the name to the device, assign to a room, and more!

You can now use the app to add voice control (see pg 10), adjust settings, create custom lighting effects, set schedules, and more!

APP CONTROL: EDIT SCENES

The **MONSTER SMART** app gives you full control over all the features of the RGBW Party Light Bar, as well as the ability to edit preset scenes to create your own custom scenes. Below are some of the editable scene features for this device.



APP CONTROL: SOUND REACTIVE

As the device is likely to be located at the perimeter of a room or a party, the sound reactive mode will react to sound collected by your microphone or headphones. To use this feature please allow microphone access when prompted in the app and leave the app running during use of this mode.



