



QUICK SET UP GUIDE

METRO VSRP-800

Dual Bluetooth® Suitcase Turntable

BASIC SETUP OF THE VSRP-800 SUITCASE TURNTABLE:

1. Connect the power adaptor to a nearby AC outlet.
2. Turn on the unit by turning the POWER/VOL knob and the power LED indicator lights up. Your system is now ready to play your music. Please refer to the Operations section of this manual for details.



PREPARE TURNTABLE FOR PLAYING RECORDS

1. Remove cap protecting stylus.
2. Remove twist tie used to secure the Tone Arm in place.

CONNECT BLUETOOTH® IN

1. Switch the knob to Bluetooth® mode. A blue LED will begin flashing and a voice indicates the turntable is in pairing mode.
2. Search for the turntable in the list of Bluetooth® devices named "VICTOR VSRP-800" and connect.
3. A chime and a steady blue LED light will indicate you have paired with the turntable successfully.



CONNECT BLUETOOTH® OUT

1. Turn on pairing mode on your Bluetooth® speaker.
2. Turn the Bluetooth® knob to the "BT Out" position on the turntable. The LED light flashes to indicate the device is searching for an available Bluetooth® speaker.
3. When the turntable connects to the Bluetooth® speaker, the LED light stays lit. After the speaker is paired successfully, turntable audio signal can be transmitted.



**This product has been manufactured and sold under the responsibility of NAXA ELECTRONICS INC. VICTOR and the DOG & GRAMOPHONE logo are trademarks used under license by NAXA ELECTRONICS INC. Further information at www.victor-brand.com. All other products, services, companies, trademarks, trade or product names and logos referenced herein are the property of their respective owners.*

READ THE ENTIRE USER MANUAL FOR COMPLETE UNDERSTANDING OF THE PRODUCT'S OPERATION