

PeakTech Models – No longer available

P 12864	LC Module	MANUAL	
P 24064	LC Module	MANUAL	
P 1006 - 1013	Generator	MANUAL	
P 610	Logic Probe	MANUAL	
p 1015	Generator	MANUAL	
P 1110	Generator	MANUAL	
P 1140	Generator	MANUAL	SOFTW.
p 1170	Generator	MANUAL	SOFTW.
P 1175 - 1180	Generator	MANUAL	SOFTW.
P 1190 - 1230	Oscilloscope	MANUAL	
P 1235	Logic Analyzer	MANUAL	
P 1280 - 1330	PC-Oscilloscope	MANUAL	SOFTW.
P 1300	Oscilloscope	MANUAL	
P 1320	Power Supply	MANUAL	
P 1325	Oscilloscope	MANUAL	SOFTW.
P 1350	Oscilloscope	MANUAL	SOFTW.
P 1895	Power Supply	MANUAL	SOFTW.
P 2005	Multimeter	MANUAL	
P 2010	Multimeter	MANUAL	
P 2015	Multimeter	MANUAL	
P 2025	Multimeter	MANUAL	
P 2020	Oscilloscope	MANUAL	
P 2035	Oscilloscope	MANUAL	
P 2040 - 4060 - 6080	Oscilloscope	MANUAL	
P 2150	LCR Meter	MANUAL	SOFTW.
P 2155	LCR Meter	MANUAL	
P 2165	LCR Meter	MANUAL	
P 2680 - 2685	Isolation Tester	MANUAL	
P 2860	Frequency counter	MANUAL	SOFTW.
P 2800	Laser Distance Meter	MANUAL	
P 3315	Multimeter	MANUAL	
P 3375	Multimeter	MANUAL	SOFTW.
P 3380	Multimeter	MANUAL	SOFTW.
P 3425	Multimeter	MANUAL	
P 3430	Multimeter	MANUAL	
P 3725	Multimeter	MANUAL	
P 4005	Multimeter	MANUAL	SOFTW.
P 4100	Universal Meas. System	MANUAL	
P 4110	Universal Meas. System	MANUAL	
P 4120	Universal Meas. System	MANUAL	
P 4123	Wall Transformer	MANUAL	
P 4130	Spectrum Analyzer	MANUAL	SOFTW.
P 4135	Spectrum Analyzer	MANUAL	SOFTW.
P 4140	Spectrum Analyzer	MANUAL	SOFTW.
P 5060	Anemometer	MANUAL	
P 5065	Lux-Meter	MANUAL	
P 5085	UV Meter	MANUAL	
P 5130	Salt Meter	MANUAL	
P 5600	Video Borescope	MANUAL	
P 5605	Thermal Imaging Camera	MANUAL	
P 5610 A	Thermal Imaging Camera	MANUAL	
P 5615	Thermal Imaging Camera	MANUAL	SOFTW.
P 5620	Thermal Imaging Camera	MANUAL	SOFTW.
P 6015 A	Power Supply	MANUAL	
P 6070 - 6075	Power Supply	MANUAL	
P 6135	Power Supply	MANUAL	
P 6140	Power Supply	MANUAL	
P 6145	Power Supply	MANUAL	
P 6150	Power Supply	MANUAL	
P 6180	Power Supply	MANUAL	SCPI
P 6205	Power Supply	MANUAL	
P 6210	Power Supply	MANUAL	
P 6225	Power Supply	MANUAL	
P 6215	Power Supply	MANUAL	
P 9020 A	Sattelite Finder	MANUAL	
P 9022	Sattelite Finder	MANUAL	
P 9040	Energy Meter	MANUAL	

Back to www.peaktech.de