



Installation guide Solenoid valve Type EV310B





032R9323

EV310B 1.5 - 3.5B NC
EV310B 1.5 - 3.5B NO




EV310B 1.5 - 3.5B NC
EV310B 1.5 - 3.5B NO




032R9323

Імпортёр:ТОВ з іі "Данфосс ТОВ" 04080, Київ 80, п/с 168, Україна

Installation




Valves with manual override




Info for UK customers only: Danfoss Ltd., 22 Wycombe End, HP9 1NB, GB


EV310B 1.5 - 3.5B NC
EV310B 1.5 - 3.5B NO



EV310B 1.5 - 3.0B NC FL
EV310B 1.5 - 3.0B NO FL




Spare parts




NC: FKM	032U2033
NO: FKM	032U2035

Spare parts FL



NO: FKM	032U2036
---------	----------

NC



NO

