


Installation guide Solenoid valve Type EV310B




032R9323


EV310B 1.5 - 3.5B NC
EV310B 1.5 - 3.5B NO




Danfoss
32U1643.10



EV310B 1.5 - 3.5B NC
EV310B 1.5 - 3.5B NO




Danfoss
32U1644.10



032R9323


Імпортёр:ТОВ з іі "Данфосс ТОВ" 04080, Київ 80, п/с 168, Україна

Installation



Danfoss
A32U1386.10


Valves with manuel override




Danfoss
A32U1386.10

Info for UK customers only: Danfoss Ltd., 22 Wycombe End, HP9 1NB, GB


EV310B 1.5 - 3.5B NC
EV310B 1.5 - 3.5B NO



EV310B 1.5 - 3.0B NC FL
EV310B 1.5 - 3.0B NO FL




Spare parts




NC: FKM	032U2033
NO: FKM	032U2035

Spare parts FL



NO: FKM	032U2036
---------	----------

NC



NO



Any information, including, but not limited to information on selection of product, its application or use, product design, weight, dimensions, capacity or any other technical data in product manuals, catalogues descriptions, advertisements, etc. and whether made available in writing, orally, electronically, online or via download, shall be considered informative, and is only binding if and to the extent, explicit reference is made in a quotation or order confirmation. Danfoss cannot accept any responsibility for possible errors in catalogues, brochures, videos and other material. Danfoss reserves the right to alter its products without notice. This also applies to products ordered but not delivered provided that such alterations can be made without changes to form, fit or function of the product.

All trademarks in this material are property of Danfoss A/S or Danfoss group companies. Danfoss and the Danfoss logo are trademarks of Danfoss A/S. All rights reserved.