

# CARSON®

## LumiVisor™

LV-10

Congratulations on selecting your new Magnified LED Head Visor! In order to achieve optimum performance, please follow instructions for proper use and care.



### INSTALLING BATTERIES

1. Located behind LED lamp, remove battery door and battery housing from compartment.
2. Insert 3 AAA batteries into battery housing according to polarity indicators printed on top and bottom of housing.
3. Place loaded battery housing into battery compartment according to polarity indicators marked on the metal contacts of battery housing.
4. Replace battery door when finished.




### USING YOUR MAGNIFIER

1. Use chart below to determine your desired magnification. Reference Fig. 1 for lenses.
  - To use Lens 2, swing the lens down until it clicks into place.
  - To use Lens 3, rotate the lens until it is positioned in front of Lens 1.

Lens Combination	Magnification
Lens 1 only	2x
Lens 1 and Lens 2	3x
Lens 1 and Lens 3	5x
Lens 1, 2, and 3	6x

Fig. 1



2. Put on head visor. To adjust head strap: Press down on buckle marked "push" to release strap lock (Fig. 2). Adjust strap to desired size and release buckle to lock in place.
3. Adjust visor up or down until the subject you are viewing is in focus. Depending on your vision, you may need to move the subject closer or further away until focused.
4. To activate LED lights, slide switch on top of visor into the "On" position (Fig. 3). Adjust the LED light position as needed to illuminate your subject.




Fig. 2




Fig. 3

## CLEANING/CARE INSTRUCTIONS

- Handle lenses with care to avoid scratching. Always store item in box when not in use.
- Clean using microfiber lens cloth only. Do not use any abrasives, chemical cleaners or solvents.
- Do not use outdoors when in direct sunlight. Do not store product in any area exposed to direct sunlight.
- Remove batteries before storing visor for an extended period.

## WARNING

Do not mix old and new batteries, batteries with different brand names or different types within brands. Different attributes may cause the battery to leak fluid, overheat or explode. Do not expose to fire or excessive heat. Inspect all batteries for signs of corrosion or leakage. Use alkaline batteries only, rechargeable batteries not recommended. Insert all batteries in the direction indicated.

### Customer Service:

If you experience any difficulties, please contact us and we will be happy to help you.



✉ [info@carson.com](mailto:info@carson.com)



✉ [uksupport@carson.com](mailto:uksupport@carson.com)



✉ [eusupport@carson.com](mailto:eusupport@carson.com)

For warranty information, visit [www.carson.com/warranty](http://www.carson.com/warranty)

**[www.carson.com](http://www.carson.com)**

Carson Optical 2070 5th Avenue, Ronkonkoma, NY 11779 | Tel: 631-963-5000