

Happy?



Not happy?



Tell your friends and family



Share your experience



Let more people know

Our friendly customer service team will work hard to put a smile back on your face. Please contact us .

Warning:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.


NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

RF Exposure Statement


To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance of 20cm the radiator your body. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter

MIRROR



Installation Instruction

1 Take out the mirror and check the quantity of accessories



Mirror x1



Allen wrench x1




Base screws x4




Adapter x1



Wall screws x2




Base x1




Magnifier x1


2 Connect the base screws to the bottom of the mirror and the base




Screws at the bottom of the mirror



1 Take out the mirror and check the quantity of accessories



Mirror x1



Allen wrench x1




Base screws x4




Adapter x1



Wall screws x2




Base x1




Magnifier x1



2 Connect the base screws to the bottom of the mirror and the base




Screws at the bottom of the mirror




3 Connect the power adapter





3 Connect the power adapter




*Turn on your phone's bluetooth, connect the "Bluetooth".



4 Congratulations! Now you can light up the mirror



4 Congratulations! Now you can light up the mirror



Long press volume down
Short press to switch to previous music



Long press to increase volume
Short press to change to the next track




Long press to turn on/off Bluetooth
When not in a call: short press to play/pause music
During a call: short press to answer/hang up the call



Turn on/off
Touch to change colors
Long press to adjust brightness

1 Take out the mirror and check the quantity of accessories



Mirror x1



Allen wrench x1




Base screws x4




Adapter x1



Wall screws x2




Base x1




Magnifier x1


2 Connect the base screws to the bottom of the mirror and the base



Screws at the bottom of the mirror



1 Take out the mirror and check the quantity of accessories



Mirror x1



Allen wrench x1



Base screws x4




Adapter x1



Wall screws x2




Base x1




Magnifier x1


2 Connect the base screws to the bottom of the mirror and the base




Screws at the bottom of the mirror





3 Connect the power adapter




*Turn on your phone's bluetooth, connect the "Bluetooth".



3 Connect the power adapter



4 Congratulations! Now you can light up the mirror



Long press volume down
Short press to switch to previous music



Long press to increase volume
Short press to change to the next track




Long press to turn on/off Bluetooth
When not in a call: short press to play/pause music
During a call: short press to answer/hang up the call



Turn on/off
Touch to change colors
Long press to adjust brightness

4 Congratulations! Now you can light up the mirror



Touch to change colors

Turn on/off

Long press to adjust brightness

NO.	CORNER	PRODUCT MODLE	SIZE	BASE SCREWS	LED BULBS	USB	TYPE-C	MAGNIFIER	INPUT VOLTAGE	OUTPUT VOLTAGE	WORKING HOURS	CRI
1	ROUND	KM-HLW1-R7050UL	700*500mm	4	14	√	√	√	100 ~240Vac	DC5V 1.1A	10000H	80
2		KM-HLW1-R7050UL- BS	700*500mm	4	14	√	√	√	100 ~240Vac	DC5V 1.1A	10000H	80
3		KM-HLW1-R8055UL	800*550mm	4	15	√	√	√	100 ~240Vac	DC5V 1.1A	10000H	80
4		KM-HLW1-R8055UL- BS	800*550mm	4	15	√	√	√	100 ~240Vac	DC5V 1.1A	10000H	80
5		KM-HLW1-R9060UL	900*600mm	5	16	√	√	√	100 ~240Vac	DC5V 1.1A	10000H	80
6		KM-HLW1-R9060UL- BS	900*600mm	5	16	√	√	√	100 ~240Vac	DC5V 1.1A	10000H	80
7		KM-HLW1-R10073UL	1000*730mm	5	21	√	√	√	100 ~240Vac	DC5V 1.1A	10000H	80
8		KM-HLW1-R10073UL-BS	1000*730mm	5	21	√	√	√	100 ~240Vac	DC5V 1.1A	10000H	80
9		KM-HLW1-R10575UL	1050*750mm	5	21	√	√	√	100 ~240Vac	DC5V 1.1A	10000H	80
10		KM-HLW1-R10575UL- BS	1050*750mm	5	21	√	√	√	100 ~240Vac	DC5V 1.1A	10000H	80
11		KM-HLW1-R12090UL	1200*900mm	6	24	√	√	√	100 ~240Vac	DC5V 1.1A	10000H	80
12		KM-HLW1-R12090UL- BS	1200*900mm	6	24	√	√	√	100 ~240Vac	DC5V 1.1A	10000H	80
13	SQUARE	KM-HLW1-R7050UL-L	700*500mm	4	14	√	√	√	100 ~240Vac	DC5V 1.1A	10000H	80
14		KM-HLW1-R7050UL- BS -L	700*500mm	4	14	√	√	√	100 ~240Vac	DC5V 1.1A	10000H	80
15		KM-HLW1-R8055UL-L	800*550mm	4	15	√	√	√	100 ~240Vac	DC5V 1.1A	10000H	80
16		KM-HLW1-R8055UL- BS -L	800*550mm	4	15	√	√	√	100 ~240Vac	DC5V 1.1A	10000H	80
17		KM-HLW1-R9060UL-L	900*600mm	5	16	√	√	√	100 ~240Vac	DC5V 1.1A	10000H	80
18		KM-HLW1-R9060UL- BS -L	900*600mm	5	16	√	√	√	100 ~240Vac	DC5V 1.1A	10000H	80
19		KM-HLW1-R10073UL-L	1000*730mm	5	21	√	√	√	100 ~240Vac	DC5V 1.1A	10000H	80
20		KM-HLW1-R10073UL-BS-L	1000*730mm	5	21	√	√	√	100 ~240Vac	DC5V 1.1A	10000H	80
21		KM-HLW1-R10575UL-L	1050*750mm	5	21	√	√	√	100 ~240Vac	DC5V 1.1A	10000H	80
22		KM-HLW1-R10575UL- BS -L	1050*750mm	5	21	√	√	√	100 ~240Vac	DC5V 1.1A	10000H	80
23		KM-HLW1-R12090UL-L	1200*900mm	6	24	√	√	√	100 ~240Vac	DC5V 1.1A	10000H	80
24		KM-HLW1-R12090UL- BS -L	1200*900mm	6	24	√	√	√	100 ~240Vac	DC5V 1.1A	10000H	80