

Dog Training Collar



CONTENT

ATTENTION	01
PACKAGE CONTENT ·····	03
PRODUCT DESCRIPTION	04
MAIN FUNCTION	06
OPERATING GUIDE	07
OTHER TOOLS FOR USE	12
PAIRING INSTRUCTIONS	13
TERMS OF USE AND LIMITATION OF LIABILITY	14
REFERENCE WEIGHTS FOR DOGS	14

ATTENTION

1 WARNING

Please do not abuse animals!!!

The dog training collar is designed to correct your dog's bad habits. Please do not use it on aggressive dogs. Using the shock function on an aggressive dog may cause a stress reaction, injury or even death to the owner or others. In case of uncertainty about the suitability of this product, please consult your veterinarian or pet trainer.

2 CAUTION

Please read the user manual carefully before use to avoid harming your dog due to improper use. Incorrect wearing is easy to make your dog's skin hurt.

- Avoid wearing it for a long time, a single wearing time should not exceed 12 hours.
- Remove the receiver every 1-2 hours if possible.
- Check the fit of wearing in case of too much pressure.
- Choose a suitable conductive silicone cap, please do not let your dog come into direct contact with metal.
- Clean the dog's neck and collar weekly with a damp cloth for electrocution.
- Check the contact area for signs of rash or pain.
- If you check for rashes or pain, stop using it immediately until the skin heals.


- Please use the supplied charging cable. Output power should not be greater than 5V1A.
- After charging the receiver, you need to press the switch to use it again. It may be necessary to reconnect after each charge, ensure that the receiver and remote control are properly paired.

3 APPLICATION

- This dog training collar is designed to make your dog realize his wrong behavior, you can use the sound or vibration function first when your dog has chewing furniture, yelling. Gradually after several commands your dog will learn that wrong behavior is not allowed.
- This product has been lab tested for dogs. However, it is not suitable for any other animals, while it should only be used for training purposes.

Note: If you have any questions about the product please contact us: **love@pawshoney.com.**

PACKAGE CONTENT








Long Contact Point






PRODUCT DESCRIPTION


Handheld Remote



Screen Content



Receiver



MAIN FUNCTION

(4) (5) (8) (5)	3 Training Modes (Vibration, Tone and Shock).
(b) + 0–99	Three-speed vibration adjustable and 0-99 shock adjustable.
***	Receiver Collar IPX7 Waterproof.
2	2-Hour Rapid Charging Lithium Polymer Battery.
%	Color display shows intensity level, power level and controlled receiver.
<i>O</i> 33	Support 2 Receiver Collars with One Remote.
Ü	Magnetic charging.
\odot	Standby time: Remote 45 days / Receiver 35 days.

OPERATING GUIDE

1. Wearing Instructions:

NOTE:


- A: The contact point must be in direct contact with the skin on the underside of the dog's neck to be effective. Check the tightness by inserting your finger between the collar and the neck after wearing.
- B: Adjust the length of the collar strap and check for proper sizing to ensure that the receiver is correctly worn in the position directly under the neck and that the collar needs to stay in place.
- C: Let your dog wear the collar receiver for a few minutes and then check the straps again. Use the other features as your dog becomes familiar with the collar receiver to avoid stress!



2. Charging Instructions:

A: Connect the Handheld Remote or Receiver to the included charging cable, the green light will come on when charging is complete, and the charging time is two hours respectively. (Receiver charging port is magnetic charging)


B: The first time to use the power is not 100% state, please charge to ensure a good use experience.




3. Receiver Switch Description:

Turn ON the Receiver: Press the ON/OFF button, LED indicator flashes green.


Turn OFF the Receiver: Hold the ON/FF button for 3 seconds, Receiver vibration, LED indicator flashes red.






4. Handheld Remote Switch Description:

Security Keypad: Slide up and down to Lock or unlock.




5. Channel Switching Instructions:

Channel switching: Press the channel button to select Receiver 1, Receiver 2 or to control both receivers at the same time.



6. Sound Functions:


Beep Button: Delivers a beep tone with non-adjustable volume to the collar.



7. Description of Vibration Function:

Vibration Button: Receiver vibrates once when pressed.


Vibration Adjustment: Adjust the intensity of the vibration with the side buttons.



8. Description of Shock Function:

Shock Button: Selecting the Shock or Enhanced Shock button produces a slight electrical shock at the receiver connection point. (Strength in safe range)


Shock Adjustment: Adjustment of 0-99 stops by right side button. (Recommended to start with up to 10 gears)



OTHER TOOLS FOR USE

A: Light Tool test

- 1. The light tool is designed to test receiver power up.
- Insert the tool into the receiver's connection point and press the electric shock button on the remote control.
- 3. The light is on to prove that the product can be used normally.



B: Receiver Replacement Tool

- 1. Replacing accessories with the receiver turned off.
- Dogs with long hair are better suited to Long Contact Point and Conductive Silicone Cap.
- 3. The mounted silicone caps must be fastened to the screw holes. In order to ensure effective use, please use the same size silicone cap.



PAIRING INSTRUCTIONS

(**Note:** You can skip this step as the device is factory-paired. When the receiver does not pair, use the following pairing method.)

A: Match the remote to the receiver:

- 1. Press and hold the receiver switch until the green light blinks rapidly.
- 2. Press any button on the remote control, if pairing is successful the receiver will beep and the green light will flash.

B: Several scenarios of unsuccessful pairings:

- 1. Confirm that the receiver and remote control are turned on.
- 2. Confirm that the power is sufficient.
- 3. Verify that it passes the light tool test.
- 4. Whether the sound/vibration/electric shock etc. function of the dog training collar can be used correctly.
- 5. Ensure that the receiver is in the effective range, exceeding the maximum distance will disconnect the connection.
- Note: If you have any other questions or the above problems cannot be solved, please contact us: love@pawshoney.com.

TERMS OF USE AND LIMITATION OF LIABILITY

- Use of this product constitutes your acceptance of all terms and conditions.
- This product is professional dog training equipment. It has been laboratory tested for safety and is suitable for daily training use.
- 3. This product is not recommended if your dog weighs less than 15 pounds or under 6 months of age. If you are not sure if this product is suitable for your dog, please consult a professional dog trainer or contact us.
- This product is intended for professional dog training only and should not be used for any other purpose.
- 5. We are not responsible for any damage caused by not following the instructions or using the product incorrectly.
- 6. Please contact us for after-sales questions about the product.
- We reserve the right to change the terms, conditions and notices of the products supplied.

REFERENCE WEIGHTS FOR DOGS

Large dogs (24+ inches tall, 88+ pounds)

Medium dog (16-24) inches tall, 24.2-66 pounds)

Small dog (10-16 inches tall, 8.8-22 pounds)

Small breed (under 10 inches tall and under 8.8 pounds)

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could

void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These

limits are designed to provide reasonable protection against harmful interference in a residential

installation. This equipment generates uses and can radiate radio frequency energy and, if not

installed and used in accordance with the instructions, may cause harmful interference to radio

communications. However, there is no guarantee that interference will not occur in a particular

installation. If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to

correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help. This device complies with part 15 of the FCC Rules. Operation is subject to the following

two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Kigmmro

love@pawshoney.com