

How to Clear Password using PE System

- Step 1: Download PE System
 - Firstly, you need to download the PE system files. Please click the link below to download the necessary files: [Download PE System Files](#)
- Step 2: Create and Enter PE System
 - In this step, you can refer to the following video tutorial: [How to Create and Enter PE System](#)
 - 1. Format the USB drive to [NTFS] format for use as the PE system. Certain models of PCs (such as AM06/AM06Pro/AM02) may require formatting to [FAT32] format.
 - 2. Copy and paste the downloaded PE system files completely into the USB drive.
- Step 3: Insert USB Drive
 - Insert the prepared USB drive into the USB port of the Mini PC.
- Step 4: Select Boot Option
 - 1. Press the [F7] key when the Mini PC is not powered on.
 - 2. Hold down the power button until the boot selection screen appears.
 - 3. Use the [↑] and [↓] keys to select the USB drive labeled with [UEFI].
 - 4. Press [Enter] to confirm and enter the PE system.
- Step 5: Open Pass Work Changer
 - In the PE system, select and open [Pass Work Changer].
- Step 6: Clear Password
 - Follow the on-screen prompts to clear the password for the local account.
- Step 7: Restart System
 - After clearing the password, select restart in the PE system. You should now be able to boot directly into the Windows system.
- These steps will help you easily clear the local account password using the PE system, allowing you to regain access to your Mini PC.