



Original	Replacement	Original	Replacement
 Standby/On	 Power	 Input/Repeat	 AV
 Eject	 Eject	 Prog Up	 Ch +
 1/Slow-	 1	 Prog Down	 Ch -
 2	 2	 TRK Up	 Vol +
 3/Slow+	 3	 TRK Down	 Vol -
 4/← Shuttle	 4	 Menu	 Menu
 5	 5	 Speed	 Format
 6/Shuttle →	 6	 Audio	 Dual
 7/▼ V.Lock	 7	 Left	 Left
 8	 8	 Tv/VCR	 TV/R
 9/▲ V.Lock	 9	 Play	 Play
 0/F.ADV	 0	 Pause	 Pause
 CLR/RST	 Exit	 Stop	 Stop
 Q-Pro	 Options	 >>	 >>
 IPC	 Smart	 <<	 <<
 Display	 Info	 Rec	 Rec
 Index	 Guide	 Up	 Up



