使用说明书

健康 舒适 释放双耳



释放双耳, 放心自由, 听音乐的同时还能聆听外面的声音 听音乐, 打电话, 玩游戏, 立体声音, 真质音效, 清晰震撼



如图示, 把耳机挂在脖子后面, 同时扬声器贴在耳朵前的颚骨上, 而不是放在耳朵上。

BT配对步骤

■ 长按 Power 键3秒, 开启耳机

- 耳机配对时,请将耳机以及手机的距离控制在1米的范围内。 ■ 开机进入 配对模式, 红蓝灯交替闪烁, (如果没有出现, 请长按名功能键3秒进入配对模式)
- 打开手机的 BT 功能,搜索 BT 设备。选择" Z8" 耳 机,如果需要输入配对码,请输入"0000".配对失败后 重复上面的操作。
- 配对成功后,蓝灯慢闪。

1、 当与设备的连接距离超出BT的有效距离 (10米或33英 尺)时,耳机将与设备断开连接。此后,一旦它们再次 处于BT有效距离范围内,它们会自动重新连接,但是,如 果BT耳机与所连设备断开超过3分钟,您可能需要双击多功 能键,以重新连接设备。

2、 如果耳机连接过设备。再次打开时, BT 耳机会自动回连上一 次的RT设备。

3、如果开机配对成功后,长按多功能键3秒重新进入配对模式, 此时别的手机可以连接到此耳机

多点连接一拖二功能

按配对步骤, 配对第一个手机后, 长按"多功能键"键让耳机重 新进入配对模式,在配对第二个BT手机。 此时使用第一个手机BT设置界面再次连接刚才断开的 Z8

充电方式

用标准的 Micro USB 充电线 (随包装附送一条)将耳机和你的个人 电脑或USB充电器即可充电。大约2小时可以充满,充电的时候 LED指示灯为红色, 充电完成后变成蓝色。


1、由于电池在储存的过程中有可能损失电量,建议在第一次使用 前先给耳机充电。

- 2、在充电的过程中耳机是不可使用的
- 3、长时间不适用,建议每个月充电一次,以保持电池寿命。
- 4、耳机在没有连接设备的情况下超过5分钟,耳机自动关机。

LED 灯提示

红色快速闪烁: 电量不足 红色常亮: 正在充电 蓝色常亮: 完成充电 蓝色与红色交替闪烁: 配对模式 蓝色慢速闪烁:已连接/正在拨打电话/正在播放音频 蓝色快速闪烁:接到来电

产品配件图



扬声器类型: 骨传导技术扬声器 待机时间:长达10天 有效距离:10米 播放时间:长达5小时(中等音量下测试数据,音量变大,时间缩短)

BT版本: 5.0

操作提示

操作	BT耳机控制	提示音
开机	长按 power 使3秒	Power on
关机	长按 power 使3秒	Power off
接听电话	单击多功能键	无
结束呼叫	单击多功能键	无
担接电话	长按多功能键 2 秒	无
音量控制	单击 "+" / "-" 健	无
警察/撤放音乐(4)	单击多功能键	无
上/下前収斂 (+)	长按 "+" / "-" 键2秒 或者双击多功能键下一曲	茏
BT 已连接		Paired
BT 已新开		Dingdong
进入配对模式	长被多功能键	Ready to pair
电池电量纸		dudu

*对不同类型的BT设备,因为不同的操作系统或者音乐播放器,此功

故障诊断及解决措施

问题	故障原因	解决措施
不能开机	检查电池是否充满电	给电池充满电
不能自动连接	BT 耳机是否进 入 特机模式	双击多功能键 或者重新开机
无缺败 BT 耶	没有进入配对模式	长按多功能键3秒

存储与维护

■请将 BT耳机存放在阴凉,干燥的地方。工作温度-10~45℃ (14~113 F)。在冷/热环境或高度潮湿的地方工作会降低电 池的寿命。

- 耳机防汗不防水。请勿将耳 机放入水里。假如有水,请使用 干净的软布搽拭干净。
- ■请使用柔软的干布清洁耳机。 ■请勿将任何尖锐物体接触耳机
- ■请勿将耳机置于温度极高或极低的环境下。

■ 长时间存储后,请在使用前先充电。

- ■请勿在潮湿的环境下给耳机充电。
- 设计和规格如有变更, 恕不另行通知

产品保修单

产品品牌. 产品型号: Z8 田白姓夕. 联系由话 联系地址 由子邮箱

购买渠道: 保修条款

1、用户购机时,随机附带有一本说明书及保修卡。用户填好 后妥善保管,作为保修凭证。

2、自购机之日起,一年之内耳机在正常使用下出现问题,持卡 用户可免费享受保修服务。以下不属于保修范围:

A 保修卡无销售单位签字或盖章:

B人为或不可抗拒因素造成损坏

C 机器正常磨损:

3、若因人为,超过保修期及不可抗拒因素造成的故障,我们将收 取维修成本

4、产品出现故障需要返厂保修时、请联系我司。并填好具体的姓

名、地址、电话及故障现象。

制造商: 地址:

电话:

网址:

User Manual

Healthy Comfortable Earsfree



You can hear outside voice while listening music.

Multifunction Button -

As show in the picture, hang the earphone on the back of the neck, and at the same time, the earphone should stick on the cheekbone in front of the ear rather than on the ear.

Long press the power button for 3 seconds to power on the

■Please keep the headphones and the cellphone in the range of 1 meters if it's the first pairing ■The red and blue lights flash alternately when entering the pairing

mode after headphones power on(if it doesn't enter pairing mode, please press the "multifunction" button for 3 seconds until the red and blue lights flash alternately) ■Open the BT set on your cell phone or the devices with BT

function. Then search the BT devices and choose pairing name " Z8 ".Enter "0000" pin code if needed.

The blue LED flash slowly when it's paired successfully

 When the distance between the headphones and the BT devices is far than 10 meters or 33 feet, the BT headphones will disconnect from the devices. After that, once the they are in the range of 33 feet, they will automatically reconnect. However, if the headphones has disconnected more than

3 minutes you may need to double click the "Multifunction Button" to reconnect the devices 2. If the headphones has paired, long press the "Multifunction Button" for 3 seconds the headphones reenter the pairing mode which other cellphone can find the BT headphones and

Connect two devices

Follow the pairing method. Pair the first cellphone, then long press the play button until the BT headphones goto pairing mode again, Pairing the second cellphone. ■ Enter the cellphone setting interface of the first cell

phone, and connect the device Z8 again

With a Micro USB cable(attach with the package)to connect will a which obstable latter will the package to contrect the headphones and the USB port of your PC or charging source, the headphones will be charged. it takes 2 hours for full charging. When charging, the LED indicator is in RED, after charging finished, the LED indicator will turn to BLUE.

 Because the battery may lose some power in the storage, here kindly suggest charging your headphones full before the first time vou use it.

2. When charging, the headphones can not be used 3.If not use headphones for a long time, suggest charging ti once a month to keep battery life

LED Indicator Red led flash quickly: low power

Keeping red led light:charging Keeping blue led light:charging complete Blue led and red led flashing alternately:pairing mode Blue led flashing slowly:connected/calling/playing music Blue led flashing quickily: incoming call
Blue led double flashing slowly:the headphones doesn'tconnect the

Product Accessories



USB cable (USB to Micro) Earplug



The speaker type: Bone conduction technology speakers Play time: Up to 5 hours(depending on the actual volume and the sound

Charging time: 2 hours Standby time: Up to 10 days Effective range: 10 meters(33 feet)

Basic Operation

Operation	Headset button controller	Warning tone
Power on	Long press power button for 3 seconds	Power on
Power off	Long press power button for 3 seconds	Power off
Answer a call	Click the multifunction button	No Buzzing
End a call	Click the multifunction button	No Buzzing
Reject a call	Long press the multifunction button for 2 seconds when call incoming	No Buzzing
Volume control	Click the vol"+"/"=" button	No Buzzing
Play or pause the music play (*)	Click the multifunction button	No Buzzing
The previous/ next song(*)	Long press "+"/"-" button for 2 seconds or double click the multifunction to switch to next	No Buzzing
BT Paired		Paired
B T disconected		Dingdong
Enter pairing mode	Long press the multifunction button	Road to pair
Low battery		dudu more times

* because of the different operation system and music player, this feture may be different

Possible reasons BSolution Check whether the Can not nower on Charging it hattery is low

Can not automatic Check if enters connection standby mode Can not discover Long press multifunction button for 3 seconds Not enter pairing mode B T headphones

Storage & Maintenance

■ Please store the BT headphones in a cool, dry place. The working temperature is -10~45 °C(14~113°F). In cold, or hot highly humid place will reduce the battery life.

When long time storage, please charge it before using

headphones resistance to water, but not waterproof, please don't put the headphones into water. If there is water on it, please use soft cloth to wipe clean

Use soft dry cloth to clean headphones

Do not use any sharp objects in connect with headphones Do not put headphones at a highter or lower temperature

Do not charge the headphones in the moist environment

ECC Castles.

CDE 14-19 Lebelling (resistance)

This district complies with part IT of the PCC Rates, Operation is religion to the following two conditions: (1) This stories not not some baseful interference. and 15 his driver and some on torribonic market authorize selections for our case soluted species.

2 15.21 Changes or paydiffering coming.

Any Changer at modifications and expensity approved by the party requestible. the properties would varie the root's authority to operate the operators.

\$ 15,500 belowanton to the non-Note: This represent has been trained and found in comply with the limits for a

Eleva B shipted devices personne to part 15 of the FCE States. Shake foots one designed to provide accountile perfection against baseled provides on a protected an electron. This apartment processes over each our reduce reduc-Expressy energy and if we installed said and in accordance with the instructions, speciation beautiful intelligence to calls communications. Horselver, there is no proposable that interference will not recor in a perhodic acetifician. If his optimiest than constituently interference to entire or which we progress, which can be determined by turning the operator off and on the war is waiterspel to by to cornect the interference by case or inner of the billioning measure.

the state of a facility for many times.

Common the imprecision had been the equipment and receive

Consent the appropriate sale on order on a review different from that to which the secretary is unsupported.

County for delay to an experienced raths TV milession for help.