# SHARPER IMAGE®

### ILLUMIGLOBE

Item No. 207832

User Guide



Thank you for purchasing the Sharper Image Illumiglobe. Please take a moment to read this guide and store it for future reference.

#### **SPECIFICATIONS**

- · 3D table lamp
- · Metal base with chrome finish
- 7 mesmerizing colors
- LED Color temperature: ~6000K
- Dimensions: 7.88" L x 7.88" W x 8.66" H
- · Weight: 6.6 lbs.
- Voltage: AC100-240VPower: DC20V 460mAMaterial: Glass + ABS
- · On/Off Switch
- · Plugs into an AC outlet

#### CAUTION

Read all the instructions and warnings carefully prior to using this product.

- · Always turn on the Illumiglobe using the On/Off switch. **WARNING:** DO NOT PULL ON THE POWER CORD.
- · The glass cover is fragile! Do not drop. Handle with care.
- · Do not store the Illumiglobe in a high temperature environment.
- Do not place the Illumiglobe near a fire or other excessively hot environment.
- Do not expose the Illumiglobe to moisture or submerge it in liquid. Always keep the Illumiglobe dry.
- · Use only the power cable that came with this device.
- · Do not disassemble the Illumiglobe or attempt to repair or modify it in any manner.
- Be cautious of excessive drops, bumps, abrasions or other impacts to the Illumiglobe.
- · If this device appears to be damaged on arrival, do not use it. Contact Sharper Image Customer Service immediately.

## **WARRANTY / CUSTOMER SERVICE**

Sharper Image branded items purchased from SharperImage.com include a 1-year limited replacement warranty. If you have any questions not covered in this guide, please call our Customer Service department at 1 (877) 210-3449. Customer Service agents are available Monday through Friday, 9:00 a.m. to 6:00 p.m. ET.