


BESTÅ



Design and Quality
IKEA of Sweden



English

WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:



ALWAYS install anti-tip device provided.








NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.


ALWAYS secure your television with an anchor device.

English

Read and follow each step of the instruction carefully.









100006




130618




113287



109049




116637




130619
130722
141027
130723
130620




118137
122971
141028
130725
119253




144342




144343
144344
144345
144346
144347




103693



114947
115988



144351
144352
144353




133203
133204
133205
133207
133206
10093227




133209
133210
133212
133211
133208
10093085



1X




115443




8X

115444


1






2





3




4







5




6




7




8




9




10




11




12







14




15




16



17





18

