


hama

XX
173069



Keyboard and Mouse Set

WKM-750









A



Diagram A illustrates the connection of the calculator to a PC. The left side shows the calculator's top edge with a USB connector and a switch labeled "CONNECT OFF ON". A large black arrow points to the "ON" position. The right side shows the back of the calculator with a large black arrow pointing to the USB connector.



B Pairing mode 2.4 GHz



C Pairing mode Bluetooth



D



+



Android



+




Windows



+



**MacOS, iOS,
iPadOS**



E




2.4 GHz







BT 1




BT 2






F







Assist = AI assistant

Fn +







hama

Service & Support



support.hama.com/00173069

☎ +49 9091 502-0

D

GB



www.hama.com/nep

Hama GmbH & Co KG
86652 Monheim / Germany
www.hama.com

All listed brands are trademarks of the corresponding companies. Errors and omissions excepted, and subject to technical changes. Our general terms of delivery and payment are applied.



xx173069/10.24