





Original	Substituto	Original	Substituto
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Info		Info
	Guide		Guide
	Mute		Mute
	Vol +		Vol +
	Vol -		Vol -
	CH+		CH +
	CH-		Ch -
	>>>		>>>
	I <<		I <<
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK/ List		Ok
	Menu		Menu
	Back		Back
	Red/ Text		Red
	Green/ Audio		Green
	Yellow Sub		Yellow
	Blue/ Find		Blue
	<<<		<<<
	Play		Play
	Pause		Pause





Original	Substituto
 >>	 >>
 St op	 St op
 Rec	 Rec
 PVR	 Smart
 FAV	 Pre Ch
 [+] / Rat i o	 3D
 Page Up	 Shi ft + Up
 Page Down	 Shi ft + Down
 [v] / Edi t	 Medi a
 F1/ Tv/ Radi o	 TV/ R
 F2/ I nput	 AV
 F3	 Subt
 F4	 Opt i ons

Original	Substituto

