







# Dining Table Assembly Instructions 16084BK\_A



## Attention

1. Prior to assembly, make sure you lay out and identify all the parts as listed below are received.
2. Tighten all nuts and bolts securely. All bolts should be hand tightened before use.
3. Should you experience any difficulty during assembly or if any parts missing or damaged, please feel free to contact us.

## Parts List

<p><b>A</b></p>  <p>Table Top 1PC</p>	<p><b>B</b></p>  <p>Table Leg 4PCS</p>	<p><b>C</b></p>  <p>Base 1PC</p>
<p><b>D</b></p>  <p>M6*30 16PCS</p>	<p><b>E</b></p>  <p>Washer 16PCS</p>	<p><b>F</b></p>  <p>Hex Key 1PC</p>


# Assembly Guide



Note: Please do not fix screws tightly before all the screws are aligned. Tighten all screws at last.

## STEP 1

E\_8PCS  
D\_8PCS



## STEP 2

E\_8PCS  
D\_8PCS

