







PS5® console (CFI-2000 model group - slim)
 Console PS5® (groupe de modèles CFI-2000 - fin)
 Console PS5® (gruppo di modelli CFI-2000 - slim)
 PS5® Konsole (CFI-2000-Modellgruppe - Slim)
 Consola PS5® (grupo de modelos CFI-2000: Slim)
 Consola PS5® (grupo de modelos CFI-2000 - fina)
 PS5®-console (CFI-2000 modelgroep - slim)
 Konsola PS5® (grupa modeli CFI-2000 – slim)
 PS5® konsol (CFI-2000 model grubu - slim)
 Консоль PS5® (группа моделей CFI-2000 – Slim)






Settings > Storage > USB Extended Storage >
 Format as USB Extended Storage

PS5® console (CFI-1000 model group)
 Console PS5® (groupe de modèles CFI-1000)
 Console PS5® (gruppo di modelli CFI-1000)
 PS5®-Konsole (CFI-1000-Modellgruppe)
 Consola PS5® (grupo de modelos CFI-1000)
 Consola PS5® (grupo de modelos CFI-1000)
 PS5®-console (CFI-1000 modelgroep)
 Konsola PS5® (grupa modeli CFI-1000)
 PS5® konsol (CFI-1000 model grubu)
 Консоль PS5® (группа моделей CFI-1000)




Settings > Storage > USB Extended Storage >
 Format as USB Extended Storage

PS4® console/Console PS4®/Console PS4®/
 PS4®-Konsole/Consola PS4®/Consola PS4®/
 PS4®-console/Konsola PS4®/
 PS4® konsol/Консоль PS4®



Settings > Devices > USB Storage Devices >
 Game Drive > Format as Extended Storage



EN To minimize electromagnetic interference (EMI), place Game Drive at least 10 cm (4 in) from the PlayStation® console.
FR Pour réduire les interférences électromagnétique, placez le Game Drive à 10 cm (4 pouces) minimum de la console PlayStation®.
IT Per minimizzare l'interferenza elettromagnetica, posizionare l'unità Game Drive ad almeno 10 cm (4 pollici) dalla console PlayStation®.
DE Um elektromagnetische Interferenzen zu minimieren, sollte zwischen der Game Drive und PlayStation®-Konsole ein Abstand von mindestens 10 cm gewahrt werden.
ES Para minimizar las interferencias electromagnéticas, coloque la Game Drive a una distancia mínima de 10 cm de la consola PlayStation®.



