

## Product Description:

- Stainless steel housing
- Cancel, Bagel, Defrost functional options
- Dual independent control panels
- 6 Bread shade settings
- 1.5 inch Extra Wide Slots for Bagels and thicker bread
- Double High Lift Level
- 2 Removable Crumb Trays in back



- **[1.5" EXTRA-WIDE 4-SLOT TOASTER]** Extra Wide 4-slice Toaster for you, toasting thin bread, thick bagel, English Muffin with Easy!
  - **[CANCEL, BAGEL and DEFROST]** It features with Cancel, Bagel, and Defrost functions. Toasting the bread easy by pressing the button, breakfast will be ready fast. One press "CANCEL" to stop toasting, "Bagel" for thick bread/bagels, and "Defrost" for recover room temp.
  - **[6 TOAST SHADE SETTINGS]** 6-level settings and Automatic Pop-Up Toaster - 6 accurate shade modes for your option to prepare your favorite taste bread. Warm-up, light brown, golden brown, crispy, and dark satisfied with your taste.
  - **[DUAL INDEPENDENT CONTROL PANELS]** Dual Independent Control Panels It equivalent to 2 toasters, prepare breakfast twice fast than a 2-slice toaster! Easy to Clean with Removable Crumb Tray!
- 
- Toasting bread faster and efficient, save time and prepare breakfast for your family members in minutes.
  - Each panel has 3 Function Buttons: CANCEL, BAGEL, DEFROST. And a 6 Bread shade settings knob.



- Slot in Width: 1.5 inch
- Slot in Length: 5.47 inch
- Wide Slots make it easy to toast a bagel, thicker bread, and English muffins.
- Auto Pop-up, easy take out and don't worry to get scalded



- On the back of the toaster is 2 removable crumb trays for you to easily cleanup the toaster.
- You don't have to put upside down the toaster to clean it, cleaning becomes easy by sliding out the tray.



- The cord can be rotated under the bottom of the toaster for store.
- Save space on your counter.

