

RFRP-HW-OT Cylinder Thermostat Wireless

Page 1 of 1

Installation Instructions

For use in normal environments.



CAUTION!

Installation and connection should only be carried out by a qualified person.


- Only qualified electricians or authorised service staff are permitted to open the thermostat.
- If the thermostat is used in a way not specified by the manufacturer, its safety may be impaired.
- Prior to setting the thermostat, it is necessary to complete all required settings described in the section.

This thermostat can be mounted directly on wall.


Important: Keep this document




1




2




3



4



5



6

