

SILICONE POPCORN POPPER

INSTRUCTIONS

- Pop out the bottom of the popcorn maker to put it in its upright position.
- Pour popcorn kernels into the popper. Fill to the bottom measurement line (approximately ¼ cup) for a half bowl of popcorn or to the upper line (approximately 1/3 cup) for a full bowl of popcorn. Be sure to not fill the kernels above the upper line!
- As desired, add 1-2 tsp. of oil to the kernels before cooking, shake to evenly distribute over the kernels. Adding more than 1-2 tsp. before cooking may scorch your popper. For best popping results, cook the popcorn without any oil or seasonings.
- Put the lid inside the bowl, making sure to not push it down and create a vacuum. A vacuum will prevent your popcorn from cooking properly and could cause it to burn.
- Cook in your microwave on high heat for 2-4 minutes, depending on the wattage of your microwave. You can also use the popcorn button on your microwave. Cook until the popping slows to approximately 2-3 seconds apart.
- Remove the popper from the microwave using the safety handles. Please note that the handles will be hot and if needed, use oven mitts to remove the popper from the microwave.
- The lid and popcorn will be hot! Use caution to remove the lid from the popper and add seasonings and oil as desired. Hold the handles to toss the popcorn to spread your seasonings.

TIPS

- We have found the best way to season popcorn is with an oil spray. Butter flavored cooking sprays work well.
- Only cook popcorn kernels in your popper. Other grains or items may cause burning.
- If you burn your popcorn and have a scorch mark on your popper, clean it with a solution of equal parts vinegar and water to remove the scorch.
- If some of the kernels do not pop, you can remove the popped kernels and cook the remaining kernels to pop them.
- 6 High altitudes may cause changes in cooking times.
- 6 Your popper is dishwasher safe.



Our Story

Zulay Kitchen is named after my extraordinary mother. Zulay. She was raised in poverty-stricken Venezuela and, against all odds, brought my brother and me to live in the US. As a single mother, she worked extra-long hours but still found time to cook healthy meals for us. At the time, I thought nothing of it. But now that I'm married with children of my own, I see how much of a super-hero mom she really was.

My wife and I created Zulay Kitchen to make shopping easier than ever in today's busy world. We believe that cooking should be fast and easy, so you have more time to enjoy with your loved ones.

Aaron Cordovez, Co-Founder of Zulay Kitchen

Lifetime Warranty and Satisfaction Guarantee

We believe in our product so much that if for any reason you are not fully satisfied, we will make it right. To register and for full details: www.zulaykitchen.com/warranty

We Are Here For You

If you have a question or need support, let us know.

Zulay Kitchen: Clearwater, Florida, USA

Message us at **≥** www.zulaykitchen.com/contact-us

Follow us on Social Media 🗗 🎯 @zulay_kitchen 💶 @zulaykitchen 📢 Zulay Kitchen

LIFETIME WARRANTY REGISTRATION



JUST A FEW STEPS AWAY:

- Open the Camera App on your phone
- Point to the code and focus your camera on the code
- Click the notification that pops up*

* If you're having trouble download a OR Code App