

# Use manual

V3. 7



Ruizu

Thank you for purchasing our products. Please read the instruction manual carefully before using the product. The product specifications are in physical form and are subject to change without notice

## preface

Thanks for using my company's music player

In order to familiarize you with the operation of this machine, we have provided a detailed user manual from which you can learn about the product introduction, usage, system setup and safety precautions. Before you use this product, be sure to read all the information randomly provided carefully, which will help you to use this product better.

We have been very careful in preparing this manual and believe that the information provided in it is correct and reliable. Please excuse any omissions and warmly welcome your corrections. If you find any problems during the use of the product, please contact us promptly. Thank you for your cooperation!

## 1. Product Safety Information


WARNING: Failure to follow these safety instructions may result in injury and danger!

- Do not fall or hit the machine violently, as this will cause serious damage or will not work properly.
- Do not open or disassemble this machine. There are no parts in it that need maintenance.
- This product should not be used in humid and high temperature environments. Do not put this product in water or any liquid. Do not expose this product to sunlight or in the waste bin. Do not place this product in the fire. The battery will explode and catch fire.
- If you do not use this product for a long time, please charge and discharge this product every 2 months.

## 2. Main product parameters

- Product size: 40 \* 35 \* 10mm (16mm with back clamp)
- Main Features: Music Playing, Bluetooth Playing, Radio Playing
- Built-in TF card: capacity 4 G-128G
- Audio format: MP3.WAV.APE.FLAC.AAC-LC and other mainstream audio format
- Compatible systems: Windows XP / VISTA / 7 / 8 / 10
- Bluetooth transmission distance: > 10 M (barrier-free blocking)
- Battery: Built-in 180mAh Lithium Battery Charging Time: Approx. 2H
- Temperature of use: 0-45 \* C (Do not use in high temperature and humid environments)
- Charging voltage: DC5V Charging current: 500 mA
- Headphone jack: Φ 3.5mm ordinary three-section headphone
- USB Transfer: USB 2.0

3. Graphic of the product framework (for keystrokes, see the functional operating instructions below\*)



- |  |                   |                       |
|--|-------------------|-----------------------|
| 1 Turn on the key                              | 2 Play Pause key  | 3 Bluetooth Mode Keys |
| 4 Cycle Mode / FM Automatic Station Search Key |                   | 5 Previous keys       |
| 6 Next track key                               | 7 Volume Add keys | 8 Volume decrease key |
| 9 Headphone jack                               | 10 USB interface  |                       |

Functional operating instructions (the "long press" is 3 seconds in the following instructions)

- Turn on key: Turn on: You need to turn the switch from 1-2 to 1-1 to automatically switch to music playback mode when you turn on. Shut down: dial from 1-1 to 1-2.
- Play Pause key: Short press for the play / pause function.
- Bluetooth mode key:

1) Under music mode, there is no Bluetooth connection state, the short press enters Bluetooth mode, and if there is no pairing record automatically enters pairing mode (red and blue lights cross rapidly flashing), Search for Bluetooth devices that can be paired. If there is a record of pairs (red and blue light cross-slow flash) Reconnect the Bluetooth device that was last connected. If you want to connect another new device, in Bluetooth mode, press the Bluetooth mode key to enter pairing mode and search for pairs of Bluetooth devices. When you connect to the device, you automatically switch back to Bluetooth music playback mode (the blue light brightens). Shortly press the Bluetooth button when not connected to the device to return to music playback mode.

2) In Bluetooth Music Mode, the Bluetooth connection state, shortly press the Bluetooth key to disconnect the current Bluetooth device, and the music playback is paused. Press once more to enter Bluetooth mode and prepare to start a new device pairing.

3) FM mode, short press the Bluetooth key, there is a connection to Bluetooth disconnect Bluetooth, no blue

- Red and blue lights cross quickly flash: Search a paired Bluetooth device
- Crossed red and blue light slow flash: pairing devices before reconnecting in Bluetooth mode
- Red light slow flash: low power alarm
- Red light brightens: in charge
- The blue light brightens long: The charge is full.

## 5. Steps of charging

Use USB digital cable, USB digital cable for data transmission, can also be used to connect charging appliances

Use a computer and a charger to charge, (the charger is not standard)

Particular note: The selected charger specification must meet the following requirements, otherwise any external or malfunction will be considered by the company as human damage,

Input: AC110-240V 50 / 60Hz Max: 100mA

Output: DC5.0V-500mA

## 6 Transfer of data

USB transmission: Connect with the computer PC through USB digital line, copy the music and other related data that need to be transmitted in the computer hard disk, and switch to the broadcaster capacity disk to paste the data transmission.