

YYK-Q71

CLIP ON WIRELESS EARBUDS

Product Manuals



If you have a question that is not listed here, please do not hesitate to contact us by email. Customer Service Department email address:

1. Package contents



①



③



②



④

Let's check first.

Make sure you have the complete set before using it. If there is anything missing, please contact the dealer where you purchased it.

Packet contents

- ① Erabuds*2
- ② Charging bin*1
- ③ Type-C charging cable*1
- ④ Product Manuals*1

2.Wearing method





- 1.check the L(left) and R (right) of the earphone. Please attach it so as not to make a mistake on the left and right.
- 2.hold your ears with one hand and pinch them like earcuffs. Adjust the position of the speaker so that it faces the ear hole.

3.Product specifications


Model	YYK-Q71
Wireless version	Bluetooth 5.3
Transmission distance	10M
Talk time	6 hours
Standby time	80 hours
Charging time	1 hour
Waterproof	IPX4
1*earbud weight	5g
Overall weight	2 * earbuds + 1 * charging compartment 42g
Color	Black
Complimentary items	charging compartment, charging cable, manual
Size	0.19in*0.29in*0.11in

4.Product Description

Microphone



Type-C port



LED display

5.Power on/off


Power on

When the main body of the earphone is removed from the charging case, the earphone will power on and automatically pair.

Power off

When the main body of the earphone is stored in the charging case, the power turns off automatically. (Charging will start.)

6.Connection Pairing



【Take out】

The LED flashes red-blue alternately for 3 seconds, then one of the earphones turns off.


【Pairing standby mode】

The LED flashes red-blue alternately for another single earphone.

【After the second use】

When the earphone is taken out, it will automatically reconnect again.

7. Button



Audio control

Function	Operation method
Play/pause music	Press left/right button once while playing music
Skip to the previous song	Press the left button twice while playing music
Skip to the next song	Press the right button twice while playing music
Turn up the volume	Hold down the right button
Turn down the volume	Hold down the left button

Incoming and call operation

Function	Operation method
Answer the phone	Press the left/right button once when calling
Hang up the phone	Press left/right button once during call
Decline call	Press the left/right button twice when calling

8. How to charge



Charging in progress



Charging complete

● Charging status of the headset

Charging in progress:

On the charging box, the LED of the headset is red, the LED of the box is flashing green, and the number inside indicates the battery capacity of the box.

Charging is complete

When the battery is fully charged, the LED on the case and the LED on the headset turn off.



When charging
(without headphones)



When charging
(with headphones inserted)



Charging completed
(with headset inserted)

● Charging status of the phone case

Charging in progress:

Charging compartment (without headphones):

The number on the charging compartment case is flashing.

Charging compartment (put in headset):

The number on the charging compartment shell is flashing. "The LED light is green."

Charging is complete:





The number shown on the charging case is 100.









9. Reset operation




- In pairing mode, turn off your phone's Bluetooth and press and hold both sides of the headset 4 times at the same time. (LED lights of both headsets are flashing red and blue alternately)
- Put the headset into the charging case and take it out again, the reset is done.

10. Safety Warning

The following instructions must be observed in order to prevent injury and property damage to the user or others. Please read the text after carefully understanding the contents of the illustrations described and be sure to follow the instructions.

 Danger	
	Do not let the charging contacts short circuit. In addition, do not carry or keep with metal necklaces, coins and other small metal items.
	Do not put into the fire, and do not heat. Do not charge, use, or place in high temperature to avoid heat, fire, and rupture.
	Do not be submerged in water and do not charge in a wet state

 Warning	
	Do not use it on aircraft or near medical equipment - radio shadows may cause it to operate.
	When using this product outdoors, pay close attention to surrounding traffic.
	Do not disassemble or modify.
	If a pacemaker is being used, keep a distance of at least 22 cm from the connected components.
	Do not charge the battery with wet hands.
	Do not subject this product to strong shocks or throwing.
	Do not allow children to come into contact with it. Accidentally wrapping the headset charging cable around your neck may cause choking.

 Attention	
	Use and store this product in a humid and less dusty place.
	When using this product, do not raise the volume too high. Continuous use of this product at a loud volume that irritates the ears for a long period of time may adversely affect hearing.

11. After-sales service

There is a warranty about this machine. We have been working hard to improve the quality and reduce the rate of defective products.

If you have any questions about the use of the product, warranty or after-sales service, technical problems, or inquiries in case of failure, please use the following inquiry address.